

American National Standard

for Arboricultural Operations—
Safety Requirements



ANSI®
Z133 - 2012
Revision of
ANSI Z133.1-2006

**American National Standard
for Arboricultural Operations—
Safety Requirements**

Secretariat

International Society of Arboriculture

P.O. Box 3129

Champaign, IL 61826-3129

www.isa-arbor.com

Approved by American National Standards Institute (ANSI) August 22, 2012

Published by

International Society of Arboriculture
P.O. Box 3129, Champaign, IL 61826-3129
www.isa-arbor.com

ISBN 978-1-881956-74-7

©2012 International Society of Arboriculture. All rights reserved. No part of this publication may be reproduced in any form, in an electronic retrieval system or otherwise, without prior written permission of the publisher.

Printed in the United States of America by Premier Print Group, Champaign, Illinois.
10 9 8 7 6 5 4 3 2 1
AT/08-12/4000

American National Standard

Approval of an American national standard requires verification by ANSI that the requirements for due process, consensus, and other criteria for approval have been met by the standards developer.

Consensus is established when, in the judgment of the ANSI Board of Standards Review, substantial agreement has been reached by directly and materially affected interests. Substantial agreement means much more than a simple majority, but not necessarily unanimity. Consensus requires that all views and objections be considered and that a concerted effort be made toward their resolution.

The use of American national standards is completely voluntary; their existence does not in any respect preclude anyone, whether he or she has approved the standards or not, from manufacturing, marketing, purchasing, or using products, processes, or procedures not conforming to the standards.

The American National Standards Institute does not develop standards and will in no circumstances give an interpretation of any American national standard. Moreover, no person shall have the right or authority to issue an interpretation of an American national standard in the name of the American National Standards Institute. Requests for interpretations should be addressed to the secretariat or sponsor whose name appears on the title page of this standard.

CAUTION NOTICE: This American national standard may be revised or withdrawn at any time. The procedures of the American National Standards Institute require that action be taken periodically to reaffirm, revise, or withdraw this standard. Purchasers of American national standards may receive current information on all standards by calling or writing the American National Standards Institute.

FOREWORD

(This foreword is not part of American National Standard Z133-2012.)

This standard was developed by arborists for the arboriculture industry under the procedures of the American National Standards Institute by the Accredited Standards Committee on Safety Requirements for Arboricultural Operations, Z133. The secretariat of the Z133 Committee is held by the International Society of Arboriculture.

The Accredited Standards Committee Z133 was organized on April 4, 1968, in response to efforts by Mrs. Ethel M. Hugg of Johnstown, New York. Mrs. Hugg's son had died while trimming trees, and this tragic incident caused her to write to federal and state authorities and to various other organizations in an attempt to have measures initiated that would make tree trimming safer.

The Z133 Committee was organized with the National Arborist Association (now the Tree Care Industry Association) as secretariat. Committee delegates included representatives of industry, labor, the academic community, government, equipment manufacturers, insurance carriers, and other interested experts. The International Shade Tree Conference (now the International Society of Arboriculture) became the secretariat of the committee in November 1969.

The initial standard was unanimously adopted by the committee on July 14, 1971, and was approved as an American National Standard on December 20, 1972.

The Z133 Committee continues to monitor arboriculture safety performance, providing interpretation and clarification of the intent of the requirements in the standard and for any adjustments or revisions of the standard.

Portions of the safety standard have been adopted by the Occupational Safety and Health Administration.

This standard is reviewed on a continual basis by the committee and reviewed by the public. Revisions have occurred in 1978, 1982, 1987, 1994, 2000, and 2006. The 2012 revision has undergone significant changes. Editorial and substantive changes have been made as a result of committee review and public comment.

There are nine annexes in this standard. All nine are informative and are not considered part of this standard.

Suggestions for improvement of this standard are welcome. They should be sent to the International Society of Arboriculture, P.O. Box 3129, Champaign, Illinois, 61826-3129.

This standard was processed and approved for submittal to ANSI by the Accredited Standards Committee on Safety Requirements for Arboricultural Operations, Z133. Committee approval of the standard does not necessarily imply that all committee members voted for its approval. At the time the Z133 Committee approved this standard, it included the following members:

H. Dennis P. Ryan III, Chair
Donald F. Blair, Vice Chair
Sharon Lilly, Secretary
Janet Huber, Editor

Organization Represented

Name of Representative

Altec Industries

Richard Germain

Josh Chard (Alt.)

American Insurance Services – NIP Group, Inc.

J. George Klinger

David Springer (Alt.)

ArborMaster, Inc.

Ken Palmer

Ralph (Rip) Tompkins (Alt.)

Arizona Public Service

Dieter Paries

Mark Hamblin (Alt.)

Aspen Tree Expert Company, Inc.

Stephen Chisholm

Asplundh Tree Expert Company

Tim Walsh

Mark Foster (Alt.)

The F.A. Bartlett Tree Expert Company

Patrick H. Flynn

Joseph Bones (Alt.)

Buckingham Manufacturing Company, Inc.

Jim Pennefeather

The Davey Tree Expert Company

Joe Tommasi

Joe Engberg (Alt.)

Edison Electric Institute

Blake Jarrett

Brian Morris (Alt.)

Husqvarna

Cary Shepherd

Gent Simmons (Alt.)

International Brotherhood of Electrical Workers

James Tomaseski

Ed Mings (Alt.)

International Society of Arboriculture

John Hushagen

KS Services

Keith D. Sheriff

Organization Represented

Lewis Tree Service, Inc.

Lucas Tree Expert Company

Massachusetts Arborist Association

McCoy Tree Surgery

National Park Service

North American Training Solutions

Penn Line Service, Inc.

SherrillTree

Sierra Moreno Mercantile Company, Inc.

Society of Municipal Arborists

Tree Care Industry Association

U.S. Department of Labor

U.S. Forest Service

Utility Arborist Association

Wright Tree Service

Yale Cordage Company, Inc.

Individual Members

Honorary Members

Name of Representative

John Sullivan

Daniel H. Oberlies (Alt.)

Gerry Breton

Arthur Batson II (Alt.)

Daniel K. Mayer

Andy Felix (alt.)

Kathryn Shaw

Eric Hanninen

Scott Prophett

A. Bruce Smith (Alt.)

Joe Jimmo

Chad Schilling (Alt.)

Tobe Sherrill

Tim Bushnell (Alt.)

Donald F. Blair

Mike Dirksen

Randall Harris (Alt.)

Jim Ostvig

Peter Gerstenberger (Alt.)

Robert Bell

Frank Castillo

Godot Apuzzo (Alt.)

David Goodson

S. Dale Crutchfield (Alt.)

Rocky Palmer

Jim Lorrigan (Alt.)

Jamie Goddard

Richard W. Hildebrand (Alt.)

Tom Dunlap

H. Dennis P. Ryan III

Richard Abbott

James C. Allard

Herschel Hale

Robert Herder

Mrs. Ethel Hugg

Edward J. Johnson

Gordon S. King

TABLE OF CONTENTS

1	GENERAL	1
	1.1 Scope	1
	1.2 Purpose.....	1
	1.3 Application	1
	1.4 Responsibilities of the Employee	1
2	NORMATIVE REFERENCES	1
3	GENERAL SAFETY REQUIREMENTS	2
	3.1 General	2
	3.2 Traffic Control.....	2
	3.3 Emergency Procedures and Readiness	2
	3.4 Personal Protective Equipment (PPE)	3
	3.5 Fire Protection	4
4	ELECTRICAL HAZARDS	4
	4.1 General	4
	4.2 Working in Proximity to Electrical Hazards.....	6
	4.3 Storm Work and Emergency Conditions: Line Clearance	7
5	SAFE USE OF VEHICLES AND MOBILE EQUIPMENT USED IN ARBORICULTURE	8
	5.1 Vehicles and Mobile Equipment	8
	5.2 Aerial Devices	10
	5.3 Brush Chippers	13
	5.4 Sprayers and Related Equipment.....	14
	5.5 Stump Cutters.....	15
	5.6 Vehicles.....	15
	5.7 Cranes and Knucklebooms.....	16
	5.8 Specialized Units.....	18
	5.9 Equipment-Mounted Winches	18

6	PORTABLE POWER HAND TOOLS.....	20
6.1	General	20
6.2	Portable Electric Power Tools	21
6.3	Chain Saws	21
6.4	Powered Pole Tools and Backpack Power Units.....	22
7	HAND TOOLS AND LADDERS	22
7.1	General	22
7.2	Cant Hooks, Cant Dogs, Peaveys, and Tonges.....	23
7.3	Wedges, Chisels, and Gouges	23
7.4	Chopping Tools.....	24
7.5	Ladders	24
8	WORK PROCEDURES	25
8.1	Ropes and Arborist Climbing Equipment	25
8.2	Pruning and Trimming	28
8.3	Cabling	29
8.4	Rigging.....	29
8.5	Tree Removal.....	31
8.6	Brush Removal and Chipping.....	34
8.7	Limbing and Bucking.....	35
8.8	Pesticide Application.....	36
8.9	Mixing Pesticides	37
8.10	High-Pressure Air-Excavation Equipment.....	37
8.11	Fertilization/Soil Management.....	38

ANNEX A	39
Glossary of Terms for ANSI Z133	
ANNEX B	49
Recommended Guidelines for Standard Performance and Safety Training for Qualified Line-Clearance Arborists/Qualified Line-Clearance Arborist Trainees and Qualified Arborists/Qualified Arborist Trainees	
ANNEX C	53
General Safety Procedures That Apply to All Tree Work	
ANNEX D	57
Additional Resources	
ANNEX E	59
Weight of Green Logs	
ANNEX F	61
Aerial Rescue Flowchart	
ANNEX G	62
Hand Signal Chart for Crane Operators	
ANNEX H	65
Electrical Hazard Abatement	
ANNEX I	67
Fall Protection Systems	
INDEX	68
RECOMMENDATIONS FORM	72

1 GENERAL

1.1 Scope

This standard contains **arboriculture** safety requirements for pruning, repairing, maintaining, and removing trees; cutting brush; and for using equipment in such operations. (Note: Terms specific to the safe practice of arboriculture appear in boldface type at first use and are defined in Annex A, the glossary.)

1.2 Purpose

The purpose of this standard is to provide safety criteria for **arborists** and other **workers** engaged in arboricultural operations. It is intended as a guide to federal, state, and local authorities in drafting their regulations and may be adopted in whole or in part.

1.3 Application

This standard is intended to apply to all **employers** engaged in the business, trade, or performance of arboriculture, including employers engaged in tree pruning, repairing, or maintaining; removing trees; cutting brush; or performing pest or soil management, who hire one or more persons to perform such work. This standard serves as a reference for safety requirements for those engaged in tree pruning, repairing, or maintaining; removing trees; cutting brush; or performing pest or soil management.

This standard may require situational modifications in response to personnel emergencies and is not intended to limit the options available to emergency responders.

1.4 Responsibilities of the Employee

Each person (employee or otherwise) **shall** be responsible for his/her own safety while on the jobsite and shall comply with the appropriate federal or state occupational safety and health standards and all rules, regulations, and orders that are applicable to his/her own actions and conduct.

2 NORMATIVE REFERENCES

This standard contains references to other American national standards and federal regulations, which, through reference in this text, constitute provisions of this American national standard. See Annex D for a list of these and other applicable informative references. At the time of publication, the editions indicated were valid. All standards are subject to revision, and parties to agreements based on this American national standard are encouraged to investigate the possibility of applying the most recent editions of the standards indicated in Annex D.

Because of the many specialized procedures utilized during arboricultural operations, it must be emphasized that exceptions to provisions of these standard may be acceptable and that flexibility and/or a decision as to the applicability of these standards to professional operations may be required.

3 GENERAL SAFETY REQUIREMENTS

3.1 General

- 3.1.1 Tools and equipment shall conform to the requirements of this standard.
- 3.1.2 Employers shall instruct their employees in the proper use, inspection, and maintenance of tools and equipment, including ropes and lines, and shall require that appropriate working practices be followed.
- 3.1.3 A **qualified arborist should** determine whether **direct supervision** is needed on a jobsite.
- 3.1.4 A **job briefing** shall be performed by the qualified arborist in charge before the start of each job. The briefing shall be communicated to all affected workers. An employee working alone need not conduct a job briefing. However, the employer shall ensure that the tasks are being performed as if a briefing were required.

3.2 Traffic Control

- 3.2.1 Traffic and pedestrian control around the jobsite shall be established prior to the start of all arboricultural operations.
- 3.2.2 Arborists and other workers having specific **temporary traffic control zone** responsibilities shall be trained in temporary traffic control techniques, device usage and placement, and how to work next to traffic in a manner that minimizes their vulnerability.
- 3.2.3 Arborists and other workers exposed to risks of moving roadway traffic shall wear high-visibility safety apparel meeting the requirements of ANSI/ISEA 107.
- 3.2.4 Vehicular traffic flow should be inhibited as little as possible while traveling through the temporary traffic control zone. Arborists and other workers should use the necessary devices that get the road user's attention and provide positive direction in accordance with the Manual on Uniform Traffic Control Devices (MUTCD).
- 3.2.5 Pedestrians should have separate movement from the work activity area and vehicular traffic with a safe, convenient, and accessible path.

3.3 Emergency Procedures and Readiness

- 3.3.1 Emergency phone numbers shall be available when and where arboricultural operations are being carried out. Arborists and other workers shall be instructed as to the specific location of such information.

- 3.3.2 A first-aid kit that meets the requirements of ANSI Z308.1 shall be provided by the employer when and where arboricultural operations are being carried out. Arborists and other workers shall be instructed in its use and specific location.
- 3.3.3 Instruction shall be provided in the identification, preventive measures, and first-aid treatment of common poisonous plants (poison ivy, poison oak, and poison sumac), stinging and biting insects, and other pests found in the area in which work is to be performed.
- 3.3.4 Employees who may be faced with a rescue decision shall receive training in emergency response and rescue procedures appropriate and applicable to the work to be performed, as well as training to recognize the hazards inherent in rescue efforts (see Annex F).
- 3.3.5 Cardiopulmonary resuscitation (CPR) and first-aid training shall be provided in the absence of an infirmary, clinic, or hospital near the worksite.

3.4 Personal Protective Equipment (PPE)

- 3.4.1 Personal protective equipment (PPE), as outlined in this section, shall be required when there is a reasonable probability of injury or illness that can be prevented by such protection.
- 3.4.2 The employer shall assess the work area to determine if hazards are present or are likely to be present. This assessment will be used to determine the type of personal protective equipment that may be required for employee protection.
- 3.4.3 Training shall be provided on the use, care, maintenance, fit, and life of personal protective equipment.
- 3.4.4 Workers engaged in arboricultural operations shall wear head protection (helmets) that conforms to ANSI Z89.1. Class E helmets shall be worn when working in **proximity to electrical conductors** in accordance with ANSI Z89.1. Workers shall not place reliance on the dielectric capabilities of such helmets.
- 3.4.5 Face protection shall comply with applicable federal regulations as well as with ANSI Z87.1.
- 3.4.6 Clothing and footwear appropriate to the known job hazards shall be **approved** by the employer and worn by the employee.
- 3.4.7 Respiratory protection shall comply with applicable federal regulations as well as with ANSI Z88.2.
- 3.4.8 Hearing protection provided by the employer shall be worn when it is not practical to decrease or isolate noise levels that exceed acceptable standards. The employer shall provide employees protection against the effects of noise exposure when sound levels exceed an 8-hour, time-weighted average (TWA) of 85 decibels (dB).

- 3.4.9 Eye protection shall comply with ANSI Z87.1 and shall be worn when engaged in arboricultural operations.
- 3.4.10 Cut-resistant **leg protection** shall be worn while operating a chain saw during ground operations.

3.5 Fire Protection

- 3.5.1 Equipment shall be refueled only after the engine has stopped. Spilled fuel shall be removed from equipment before restarting.
- 3.5.2 Equipment shall not be operated within 10 feet (3.05 m) of refueling operations or areas in which refueling has recently taken place.
- 3.5.3 Flammable liquids shall be stored, handled, and dispensed from **approved containers**.
- 3.5.4 Smoking shall be prohibited when handling or working around flammable liquids.
- 3.5.5 Clothing contaminated by flammable liquid shall be changed as soon as possible.
- 3.5.6 Open flame and other sources of ignition shall be avoided.

4 ELECTRICAL HAZARDS

4.1 General

- 4.1.1 All overhead and underground electrical conductors and all communication wires and cables shall be considered energized with potentially fatal voltages.
- 4.1.2 The employer shall certify that each employee has been trained to recognize and is appropriately qualified to work within proximity to electrical hazards that are applicable to the employee's assignment.
- 4.1.3 Arborists and other workers shall be instructed that
 - (a) the human body's good conductive properties pose little resistance to electric current and provide a path for the flow of electricity to a **grounded** object or to the ground itself;
 - (b) **direct contact** or **indirect contact (phase-to-ground contact)** with an electrical conductor, energized tree limb, tool, or equipment, or other energized object may lead to electrocution or other significant and/or fatal injury;
 - (c) simultaneous contact with two separate energized conductors (**phase-to-phase contact**) will cause electric shock that may result in serious or fatal injury;

Table 1. Minimum approach distances from energized conductors for qualified line-clearance arborists and qualified line-clearance arborist trainees.

Nominal voltage in kilovolts (kV) phase-to-phase	Includes 1910.269 elevation factor, sea level to 5,000 ft (1524 m)*		Includes 1910.269 elevation factor, 5,000–10,000 ft (1524–3048 m)*		Includes 1910.269 elevation factor, 10,001–14,000 (3048–4267 m)*	
	ft-in	m	ft-in	m	ft-in	m
0.051 to 0.3	<i>Avoid contact</i>		<i>Avoid contact</i>		<i>Avoid contact</i>	
0.301 to 0.75	1-01	0.33	1-03	0.38	1-04	0.41
0.751 to 15.0	2-05	0.70	2-09	0.81	3-00	0.88
15.1 to 36.0	3-00	0.91	3-05	1.04	3-09	1.00
36.1 to 46.0	3-04	1.01	3-10	1.16	4-02	1.09
46.1 to 72.5	4-02	1.26	4-09	1.44	5-02	1.30
72.6 to 121.0	4-06	1.36	5-02	1.55	5-07	1.68
138.0 to 145.0	5-02	1.58	5-11	1.80	6-05	1.96
161.0 to 169.0	6-00	1.80	6-10	2.06	7-05	2.23
230.0 to 242.0	7-11	2.39	9-00	2.73	9-09	2.95
345.0 to 362.0	13-02	3.99	15-00	4.56	16-03	4.94
500.0 to 550.0	19-00	5.78	21-09	6.60	23-07	7.16
765.0 to 800.0	27-04	8.31	31-03	9.50	33-10	10.29

*Exceeds phase-to-ground; elevation factor per 29 CFR 1910.269.

- (d) electrical shock may occur as a result of **ground fault** when a person stands near a grounded object (for example, if an uninsulated **aerial device** comes into contact with a conductor with **outriggers** down);
- (e) in the event of a downed energized electrical conductor or energized grounded object, there exists the hazard of **step potential**.

4.1.4 If the **minimum approach distance** (shown in Table 1) cannot be maintained during the arboricultural operations, the **qualified line-clearance arborist** shall request that the **electrical system owner/operator's** designated supervisor in charge coordinate communications and operations between the electrical system owner/operator and the qualified line-clearance arborist to **mitigate** the electrical hazard. Mitigation options should include all safe, OSHA-compliant,

Table 2. Minimum approach distances to energized conductors for persons other than qualified line-clearance arborists and qualified line-clearance arborist trainees.

Nominal voltage in kilovolts (kV) phase-to-phase*	Distance	
	ft-in	m
0.0 to 1.0	10-00	3.05
1.1 to 15.0	10-00	3.05
15.1 to 36.0	10-00	3.05
36.1 to 50.0	10-00	3.05
50.1 to 72.5	10-09	3.28
72.6 to 121.0	12-04	3.76
138.0 to 145.0	13-02	4.00
161.0 to 169.0	14-00	4.24
230.0 to 242.0	16-05	4.97
345.0 to 362.0	20-05	6.17
500.0 to 550.0	26-08	8.05
785.0 to 800.0	35-00	10.55

*Exceeds phase-to-ground per 29 CFR 1910.333.

and practical work methods, and, where necessary, **de-energizing, testing**, isolating, and grounding the electrical conductors by the electrical system owner/operator (see Annex H). The designated electrical system owner/operator employee and the designated qualified line-clearance arborist in charge shall confirm that protective ground(s) have been installed as close as practical to the **line clearance** work to be performed to prevent hazardous differences in electrical potential.

4.1.5 Non-line-clearance-qualified arborists shall maintain the minimum approach distances shown in Table 2 at all times.

4.2 Working in Proximity to Electrical Hazards

4.2.1 The items contained in section 4.1 shall always be included in the review of this section.

4.2.2 An inspection shall be made by a qualified arborist to determine whether an electrical hazard exists before climbing, otherwise entering, or performing work in or on a tree.

4.2.3 Only qualified line-clearance arborists or **qualified line-clearance arborist trainees** shall be assigned to work where an electrical hazard exists. Qualified line-clearance arborist trainees shall be under the direct supervision of qualified line-clearance arborists.

4.2.4 A second qualified line-clearance arborist or line-clearance arborist trainee shall be within visual or voice communication during line-clearing operations aloft when a qualified line-clearance arborist or line-clearance arborist trainee must approach closer than 10 feet (3.05 m) to any energized electrical conductor in excess of 750 volts (**primary conductor**) or when

(a) branches or limbs are being removed, which cannot first be cut (with a nonconductive pole pruner/pole saw) to sufficiently clear electrical conductors, so as to avoid contact; and/or

(b) roping is required to remove branches or limbs from such electrical conductors.

4.2.5 Qualified line-clearance arborists and line-clearance arborist trainees shall maintain minimum approach distances from energized electrical conductors in accordance with Table 1.

4.2.6 All other arborists and other workers shall maintain a minimum approach distance from energized electrical conductors in accordance with Table 2.

4.2.7 Branches contacting an energized electrical conductor shall be removed using nonconductive equipment.

- 4.2.8 The tie-in position should be above the work area and located in such a way that a slip would swing the arborist away from any energized electrical conductor or other identified hazard.
- 4.2.9 While climbing, the arborist should climb on the side of the tree that is away from energized electrical conductors while maintaining the required distances shown in Table 1 or 2, as applicable.
- 4.2.10 Footwear, including lineman's overshoes or those with electrical-resistant soles, shall not be considered as providing any measure of safety from electrical hazards.
- 4.2.11 Rubber gloves, with or without leather or other protective covering, shall not be considered as providing any measure of safety from electrical hazards.
- 4.2.12 A rope that is wet, that is contaminated to the extent that its insulating capacity is impaired, or that is otherwise not to be considered insulated for the voltage involved may not be used within the minimum approach distances shown in Table 1 or 2, as applicable.
- 4.2.13 **Ladders**, platforms, and aerial devices, including insulated aerial devices, shall be subject to minimum approach distances in accordance with Table 1 or 2, as applicable.
- 4.2.14 Aerial devices with attached equipment (such as chippers) brought into contact with energized electrical conductors shall be considered energized. Contact by people and/or equipment shall be avoided.
- 4.2.15 Emergency response to an electric contact shall be performed in accordance with section 3.3, Emergency Procedures and Readiness.

4.3 Storm Work and Emergency Conditions: Line Clearance

- 4.3.1 The items contained in section 4.1 shall always be included in the review of this section.
- 4.3.2 Line clearance shall not be performed during adverse weather conditions, such as thunderstorms, high winds, and snow and ice storms.
- 4.3.3 Qualified line-clearance arborists and qualified line-clearance arborist trainees performing line clearance after a storm or under similar conditions shall be trained in the special hazards associated with this type of work and in the recognition of the hazards of step potential.
- 4.3.4 Line-clearance operations shall be suspended when adverse weather conditions or emergency conditions develop involving energized electrical conductors. Electrical system owners/operators shall be notified immediately.

5 SAFE USE OF VEHICLES AND MOBILE EQUIPMENT USED IN ARBORICULTURE

5.1 Vehicles and Mobile Equipment

- 5.1.1 A pre- and post-trip inspection of any vehicles and mobile equipment (units), visual walk-around inspections, and operational checks shall be made in accordance with manufacturers' and owners' instructions, applicable Federal Motor Carrier Safety Regulations (FMCSR), and state and local requirements.
- 5.1.2 Units shall be equipped and maintained with manufacturers' safety devices, instructions, decals, and safeguards. Arborists and other workers shall follow instructions provided by manufacturers.
- 5.1.3 Manufacturers' preventive maintenance inspections and parts replacement procedures shall be followed.
- 5.1.4 Manufacturers' instructions shall be followed in detecting hydraulic leaks. No part of the body shall be used to locate or stop hydraulic leaks.
- 5.1.5 Units shall be operated and maintained only by **authorized and qualified personnel** in accordance with the manufacturers' safe operating procedures, company policies, and federal, state, and local laws.
- 5.1.6 Material and equipment carried on vehicles shall be properly stored and secured in compliance with the design of the unit and in accordance with federal, state, and local regulations (including, but not limited to, FMCSR) in order to prevent the movement of material or equipment.
- 5.1.7 Stepping/walking/working surfaces on mobile equipment shall be skid-resistant.
- 5.1.8 Safety seatbelts, when provided by the manufacturer, shall be worn by the driver and passenger(s) while the vehicle is in motion.
- 5.1.9 While performing proper maintenance and inspection as instructed by the manufacturer, riding or working outside or on top of units shall not be permitted unless the units are designed for that purpose.
- 5.1.10 Hoisting or lifting equipment on vehicles shall be used within rated capacities as stated by the manufacturers' specifications.

- 5.1.11 Units with an obstructed view to the rear, particularly those with towed equipment, should be backed up only when absolutely necessary. The vehicle shall not be backed up unless the vehicle has a reverse signal alarm audible above the surrounding noise level; the vehicle is backed up only when a designated observer or ground guide signals that it is safe to do so; or, immediately before backing up, the driver determines through a visual walk-around inspection that there are no people or obstructions in the path of the vehicle.
- 5.1.12 When units are left unattended, keys shall be removed from the ignition, the wheels chocked, and, if applicable, the parking brake applied.
- 5.1.13 Units shall be turned off, keys removed from the ignition, and rotating parts at rest prior to making repairs or adjustments, except where manufacturers' procedures require otherwise. Defects or malfunctions affecting the safe operation of equipment shall be corrected before such units are placed into use (see Annex C, General Safety Procedures That Apply to All Tree Work).
- 5.1.14 Personal protective equipment (for example, eye, head, hand, and ear protection) shall be worn in accordance with section 3.4, Personal Protective Equipment.
- 5.1.15 When towing, safety chains shall be adjusted to an appropriate length, crossed under the tongue of the unit being towed, and connected to the towing vehicle. When applicable, all other coupling devices shall be in place (e.g., pins, electrical connections, electric brakes, emergency break-away devices). Towing units shall meet weight capacities necessary for the intended load/cargo.
- 5.1.16 Care should be taken to ensure that a unit's exhaust system does not present a fire hazard.
- 5.1.17 Towed units that are detached from another unit (for example, a motorized vehicle) shall be chocked or otherwise secured in place.
- 5.1.18 Units operated off-road shall be operated in the proper gear and at the proper speed relative to the operating environment and the manufacturers' instructions and guidelines.
- 5.1.19 Rollover protection shall meet the requirements of the applicable line publication of the Society of Automotive Engineers (SAE) Standard J167.
- 5.1.20 When protective enclosures are used on wheel-type agricultural and industrial tractors, they shall meet the requirements of Society of Automotive Engineers (SAE) Standard J168-1970 (Protective Enclosures—Test Procedures and Performance Requirements).

5.2 Aerial Devices

- 5.2.1 The items contained in section 5.1 shall always be included in the review of this section.
- 5.2.2 Before the aerial device is set up for use, the worksite shall be surveyed for hazards, such as
- (a) insufficient supporting surfaces, such as soft ground or tamped earth fills
 - (b) ditches
 - (c) excessive slopes, drop-offs, curbs, and floor obstructions
 - (d) debris
 - (e) overhead obstructions and electrical conductors
 - (f) weather conditions
 - (g) presence of unauthorized persons
 - (h) road or worksite traffic
 - (i) subsurface chambers, such as underground utility components or septic systems
- 5.2.3 Aerial devices or aerial ladders shall not be used as cranes or hoists to lift, support, or lower materials or tree parts unless they were specifically designed by the manufacturer to do so.
- 5.2.4 **Wheel chocks** shall be set before using an aerial device unless the device has no wheels on the ground or is designed for use without chocks.
- 5.2.5 Outriggers or stabilizers shall be used if manufacturers' instructions require their use. All outriggers shall be properly set on pads or a solid surface before the aerial device is moved from the boom rest (cradle).
- 5.2.6 Outrigger pads shall be placed under outrigger feet when they are needed to provide firm footing.
- 5.2.7 The operator of the outrigger controls shall ensure adequate clearance exists and give warning to all workers in the work area prior to lowering outriggers.
- 5.2.8 Aerial devices shall be provided with fall protection anchor(s) meeting design requirements of the ANSI/SIA A92.2 Standard on which to secure an approved system of personal fall protection (for example, full body harness with an energy-absorbing **lanyard** or a body belt and lanyard), which shall be worn by the operator(s) whenever aloft.
- 5.2.9 Combined loads shall not exceed rated lift capacities. Load ratings shall be permanently posted on aerial devices in accordance with ANSI/SIA A92.2 or A92.5, as applicable to the specific aerial device.
- 5.2.10 One-person **buckets** shall not have more than one person in them during operations.
- 5.2.11 The operator shall stand firmly on the floor of the bucket and shall not use railings, planks, ladders, or any other device in or on the bucket for achieving additional working height.

- 5.2.12 Climbing spurs (gaffs) shall not be worn while working from an aerial device.
- 5.2.13 A sheath or scabbard shall be utilized in the bucket to cover sharp-edged tools, such as chain saws and hand saws (unless of the folding type that covers the cutting teeth when closed), while stored for use.
- 5.2.14 A hand saw should be taken by the aerial device operator/climber while working aloft.
- 5.2.15 Before engaging in mobile operation, the operator shall determine that the aerial device is specifically designed for mobile operations.
- 5.2.16 Before moving an aerial device for travel, the operator shall inspect the aerial device to ensure the boom(s) are properly cradled and the outriggers are in the stowed position.
- 5.2.17 When operating aerial devices, the operator shall look primarily in the direction the bucket is traveling and be aware of the location of the booms in relation to all other objects and hazards.
- 5.2.18 When transferring from the bucket of an aerial device to a tree in order to complete an arboricultural operation, arborists shall remain **secured** to the aerial device until they are properly secured to the tree. At no time shall work be performed while an arborist is secured to both aerial device and tree.
- 5.2.19 Arborists shall remain properly secured at all times when transferring from the bucket of an inoperative aerial device to the bucket of an operative aerial device to facilitate an emergency descent.
- 5.2.20 The lower controls of an aerial device shall not be used for continuous operation when the operator is in the bucket.
- 5.2.21 Clearances from passing vehicles shall be maintained or traffic control shall be provided when booms or buckets are operated over roads in accordance with the Manual on Uniform Traffic Control Devices (MUTCD), Part 6.
- 5.2.22 Workers shall not perform arboricultural operations work, such as pruning or cutting of trees, from the top of vehicle bodies or cab protectors unless the worker is properly protected from the fall hazard.
- 5.2.23 Hydraulic/pneumatic tools shall be disconnected when they are being serviced or adjusted, except where manufacturers' procedures require otherwise.
- 5.2.24 To avoid flying particles or whipping hydraulic/pneumatic hoses, pressure shall be released before connections are broken, except where **quick-acting connectors** are used. Hydraulic/pneumatic hoses shall never be kinked in order to cut off pressure.

- 5.2.25 No part of the body shall be used to locate or stop hydraulic leaks.
- 5.2.26 Hoses affecting dielectric characteristics of equipment shall meet manufacturers' requirements.
- 5.2.27 The flash point of hydraulic fluid shall meet the requirements set by the manufacturer.
- 5.2.28 Booms, buckets, or any other part of the aerial device shall not be allowed to make contact or violate minimum approach distances with energized electrical conductors, poles, or similar conductive objects.
- 5.2.29 Electric cables/cords used with electric saws, lights, or other conductive material shall not be run from the vehicle to the bucket when arborists are working in proximity to energized electrical conductors.
- 5.2.30 (a) Buckets on insulated aerial devices shall have no through-cracks or holes below the lip of the platform.
- (b) Insulating liners shall have no holes below the lip of the liner or vertical cracks greater than 5 inches (12.7 cm) long.
- 5.2.31 During aerial device operations, arborists and other workers who are not qualified line-clearance arborists shall maintain a minimum approach distance from energized electric conductors in accordance with Table 2 of this standard. Only qualified line-clearance arborists or qualified line-clearance arborist trainees using an insulated aerial device may operate in accordance with minimum approach distances provided in Table 1 of this standard.
- 5.2.32 Arborists and other workers shall be instructed that insulated aerial buckets do not protect them from other electric paths to the ground, such as paths through trees or guy wires or from phase-to-phase contact. Either form of electric contact can be fatal.
- 5.2.33 Aerial devices equipped with an elevating structure that raises the turret and booms and changes the reach of the device's uninsulated portions shall be positioned so that the uninsulated portions cannot approach energized electric lines or equipment any closer than the minimum approach distances specified in this standard. Arborists and other workers shall use **spotters** when necessary and keep workers on the ground clear of the vehicle and attachments if the aerial device may become energized.
- 5.2.34 Arborists using a **boom-supported elevating work platform** shall operate the platform within the limits of intended use as defined by the manufacturer in the operator's manual, ANSI/SIA A92.5, and applicable governmental regulations.

- 5.2.35 Only operators who have received instruction and training regarding the inspection, application, responsibilities, and operation shall operate a boom-supported elevating work platform. The operator shall be informed of the location of the manual and familiarized with the controls, safety devices, and operating characteristics of the work platform being operated.
- 5.2.36 The operator of an uninsulated boom-supported elevating work platform shall maintain minimum approach distances from energized electric conductors in accordance with Table 2 of this standard.
- 5.2.37 Insulated boom-supported elevating work platforms shall meet the electric safety requirements of ANSI/SIA A92.2.
- 5.2.38 The operator shall assess the worksite hazards present that pertain to the use of a boom-supported elevating work platform on that worksite. The operator and other workers shall develop, communicate, and implement a work plan to mitigate the hazards identified on that worksite.

5.3 Brush Chippers

- 5.3.1 The items contained in section 5.1 shall always be included in the review of this section.
- 5.3.2 Access panels and guards for maintenance and adjustment, including discharge chute and cutter housing, shall be closed and secured prior to starting the engine of brush chippers. These access panels shall not be opened or unsecured until the engine and all moving parts have come to a complete stop and ignition key removed and secured (see Annex C.2, General Safety Procedures That Apply to All Tree Work).
- 5.3.3 Rotary drum or disc brush chippers not equipped with a mechanical infeed system shall be equipped with an infeed hopper not less than 85 inches (2.15 m) measured from the blades or knives to ground level over the center line of the hopper. Side members of the infeed hopper shall have sufficient height so as to prevent workers from contacting the blades or knives during operations.
- 5.3.4 Rotary drum or disc brush chippers not equipped with a mechanical infeed system shall have a flexible anti-kickback device installed in the infeed hopper to reduce the risk of injury from flying chips and debris.
- 5.3.5 Chippers equipped with a mechanical infeed system shall have a quick-stop and reversing device on the infeed system. The activating mechanism for the quick-stop and reversing device shall be located across the top, along each side, and close to the feed end of the infeed hopper within easy reach of the worker.

- 5.3.6 Vision, hearing, and/or other appropriate personal protective equipment shall be worn when in the work area of a brush chipper in accordance with section 3.4, Personal Protective Equipment.
- 5.3.7 Arborists, mechanics, and other workers shall not, under any circumstances, reach into the infeed hopper when the cutter disc, rotary drum, or feed rollers are moving.
- 5.3.8 See section 8.6, Brush Removal and Chipping, for additional requirements.

5.4 Sprayers and Related Equipment

- 5.4.1 The items contained in section 5.1 shall always be included in the review of this section.
- 5.4.2 Working and walking surfaces of all sprayers and related equipment shall be covered with skid-resistant material.
- 5.4.3 Equipment on which the **applicator**/operator stands while the vehicle is in motion shall be equipped with guardrails around the working area. Guardrails shall be constructed in accordance with ANSI A1264.1.
- 5.4.4 All fittings and hoses shall be of sufficient strength to withstand or exceed the maximum pressure of the system.
- 5.4.5 The operator shall be aware of the location and use of all safety shut-off valves.
- 5.4.6 All tanks shall have means to determine the level of liquid in the tanks without opening the tank lid.
- 5.4.7 The applicator/operator shall make a visual inspection of hoses, fittings, exposed plumbing, tanks, covers, and related equipment prior to its use each workday.
- 5.4.8 The applicator/operator shall not allow hoses or other parts of the equipment to create a tripping hazard for coworkers or the public.
- 5.4.9 The applicator/operator shall have a firm grip on the spray gun/excavation tool when pulling the trigger.
- 5.4.10 Entering enclosed tanks or spaces shall be prohibited unless performed through a confined-space entry plan in compliance with OSHA 1910.146 requirements, which include atmospheric quality testing, training, personal protective equipment, supervision, and emergency response procedures.

5.4.11 Related equipment

- 5.4.11.1 The applicator/operator shall be aware of underground utility locations when drilling holes in the ground for fertilizer or pesticide applications.
- 5.4.11.2 The equipment shall have splashguards, and the applicator shall wear eye protection when injecting liquid fertilizer or pesticides into the ground.
- 5.4.11.3 The applicator shall wear eye protection and follow label instructions when injecting liquids into trees.

5.5 Stump Cutters

- 5.5.1 The items contained in section 5.1 shall always be included in the review of this section.
- 5.5.2 Stump cutters shall be equipped with enclosures or guards that reduce the risk of injury during operation. Enclosures or guards shall be kept in place when stump cutters are operative.
- 5.5.3 Arborists and other workers in the stump-cutting work area shall wear eye, hearing, and other personal protective equipment in accordance with section 3.4, Personal Protective Equipment.
- 5.5.4 The operator shall be aware of underground utility locations prior to performing work. All work shall be in compliance with federal, state, and local underground facility protection laws.

5.6 Vehicles

- 5.6.1 The items contained in section 5.1 shall always be included in the review of this section.
- 5.6.2 Regulated vehicles (those in excess of 10,000 pounds (4536 kg) gross vehicle weight rating, or gross combined vehicle weight rating) shall be operated in compliance with the Federal Motor Carrier Safety Regulations (FMCSR), state, and local laws.
- 5.6.3 A steel bulkhead or equivalent protective devices shall be provided to protect workers from load shifts in vehicles carrying logs or other material.
- 5.6.4 Load securement procedures shall be followed to prevent accidental shifting or discharge of logs or other materials from the vehicle during transport.
- 5.6.5 Logs or other material shall not overhang the sides; obscure taillights, brake lights, or vision; or exceed height limits per state and local requirements for bridges, overpasses, utility lines, or other overhead hazards.
- 5.6.6 To avoid the hazard of spontaneous combustion, wood chips should not be left in vehicles for extended periods.

5.7 Cranes and Knucklebooms

- 5.7.1 The items contained in section 5.1 shall always be included in the review of this section.
- 5.7.2 Cranes shall be inspected in accordance with ASME B30.5 or ASME B30.22 (articulating boom) standards and manufacturers' guidelines. Rigging equipment shall be inspected before each use in accordance with OSHA 1910.184 and manufacturers' guidelines.
- 5.7.3 Operators of hoisting equipment shall be trained and shall maintain a 10-foot (3.05-m) minimum approach distance from unguarded, overhead energized conductors, or greater separation in accordance with Table 2 of this standard. A spotter shall be used when work is being performed that could encroach on minimum approach distances from energized conductors. The spotter shall be positioned to effectively gauge the clearance distance and give timely information to the **qualified crane operator**.
- 5.7.4 Only a qualified crane operator shall be used.
- 5.7.5 Cranes shall be equipped to comply with the design standards published in ASME B30.5 or ASME-B30.22 (for articulating booms).
- 5.7.6 Hooks on overhaul ball assemblies, lower load blocks, or other attachment assemblies shall be of a type that can be closed and locked, eliminating the hook throat opening.
- 5.7.7 Crane operators shall remain at the controls while a load is **suspended**.
- 5.7.8 Tree sections shall be rigged to minimize load shifting. Controlled load lowering shall be used. **Shock-loading** shall be avoided, and free fall is prohibited.
- 5.7.9 The qualified arborist shall estimate the weight of the tree section to be suspended prior to cutting the section. The load weight estimate shall be communicated to the crane operator. After the pick is complete, the crane operator should verify, compare, and communicate the estimated weight to the qualified arborist. A green log weight chart (as shown in Annex E) shall be available to the crew. The suspended load should not exceed 80 percent of the load chart capacity of the crane.
- 5.7.10 The qualified crane operator and the **crew leader** shall meet prior to the work to review procedures to be followed. If the work involves a **designated signal person** and/or an additional qualified arborist being hoisted by the crane, these persons shall participate in the review as well. A job briefing shall be done before any work begins in accordance with subsection 3.1.4.
- 5.7.11 Cranes shall be set up in accordance with manufacturers' specifications.

- 5.7.12 Radio communication between the qualified arborist and qualified crane operator should be used during **blind picks**. Radio communication should be hands-free.
- 5.7.13 A qualified arborist may be hoisted into position utilizing a crane if he/she is **tied in** with an **arborist climbing line** and **arborist saddle** and secured to an anchor point on or above the crane hook or to the crane boom. The following procedures shall be followed when a qualified arborist is to be hoisted by a crane:
- 5.7.13.1 Only a qualified person shall authorize the use of a crane for hoisting a qualified arborist into position when he/she has determined that it is the safest and/or only feasible method to perform the work or gain access to a tree.
 - 5.7.13.2 The arborist climbing line shall be secured to the crane in such a way that it does not interfere with the function of any of the crane's components. No part of the crane shall be allowed to compromise the climbing line or any component of the climbing system. The qualified arborist shall use a second point of attachment on or above the crane hook or to the crane boom while being hoisted into position in the tree.
 - 5.7.13.3 Constant communication between the crane operator and the qualified arborist being hoisted shall be maintained, either directly or through a designated signal person, using two-way radio, vocal communication, or accepted hand signals (see Annex G).
 - 5.7.13.4 The qualified crane operator shall remain at the controls while the qualified arborist is attached to the crane.
 - 5.7.13.5 When the qualified arborist is being hoisted, hoisting speed shall not exceed 100 feet/minute (0.5 m/sec). During hoisting operations, there shall be no sudden acceleration or deceleration of the moving load.
 - 5.7.13.6 The load-line hoist drum shall have a system or other device on the power train, other than the load hoist brake, that regulates the lowering speed of the hoist mechanism.
 - 5.7.13.7 The crane carrier shall not travel at any time while a qualified arborist is attached.
 - 5.7.13.8 An accurate estimation of the **load radius** to be used during lifting shall be made before a qualified arborist is hoisted.

5.7.13.9 The qualified arborist shall be detached from the crane any time a load is suspended.

EXCEPTION

When it has been determined that all reasonably possible alternate methods are inaccessible and attachment to the subject tree would create a greater safety risk due to its hazardous condition, the qualified crane operator and the qualified arborist shall allow the qualified arborist to remain attached to the crane while a load is suspended. Possible alternate methods include, but are not limited to

- (a) the qualified arborist securing to the tree and detaching from the crane before it comes under load;
- (b) using a second crane;
- (c) using an aerial lift device; or
- (d) using an adjacent tree.

5.7.13.9.1 When the qualified arborist is attached to the crane with a suspended load, the total weight shall not exceed 50 percent of the load capacity for the radius and configuration of the crane.

5.7.13.9.2 The qualified arborist shall descend to the ground as soon as he/she has determined that the piece is detached from the tree and that it is safe to do so.

5.8 Specialized Units

5.8.1 The items contained in section 5.1 shall always be included in the review of this section.

5.8.2 Off-road and tracked vehicles shall be operated according to the operating environment and the manufacturer's instructions and guidelines.

5.8.3 Towing equipment for **brush hogs** and similar implements should be equipped with a **deadman control**. When deadman controls are not available, the worker shall disengage the power source to the rotary or cutter head before dismounting.

5.9 Equipment-Mounted Winches

5.9.1 The items contained in section 5.1 shall always be included in the review of this section.

5.9.2 Operators shall wear the appropriate personal protective equipment (PPE) during winch operations.

- 5.9.3 Each day before being used, the winch line and all fastenings and attachments shall be inspected for damage or defects by a qualified person. Additional inspections shall be performed during winch line use, where service conditions warrant. Damaged or defective winch lines shall be immediately removed from service.
- 5.9.4 Winch line hooks and attachment points shall be inspected for damage. Damaged hooks or attachment assemblies shall be taken out of service.
- 5.9.5 All mounting bolts and hardware shall be inspected for loose or missing components. The winch shall not be used until complete repairs are made to damaged or missing bolts and hardware.
- 5.9.6 Operators shall be aware of the dangers of load or winch line breakage and ensure that all personnel remain clear of the recoil area in the event of load or winch line breakage.
- 5.9.7 All winch operators shall be properly trained and be aware of the inherent dangers associated with winch operations.
- 5.9.8 Operators shall be aware of the winch line at all times during extension and ensure that it does not become a hazard to personnel or machinery.
- 5.9.9 Winch systems and winch lines shall be used only as intended and instructed by the manufacturer.
- 5.9.10 The winch shall never be used with personnel, including the operator, within the span of the winch line and the winch.
- 5.9.11 Pinch point hazards develop during winching operations; therefore, all operators involved in the winching operation shall constantly be aware of such hazards and stand clear of these areas.
- 5.9.12 All loads shall be pulled in such a manner as to avoid angles that may result in tipping, cause the vehicle to become unstable, or result in unintended movement of the vehicle.
- 5.9.13 Pulling loads from the side requires special equipment and techniques. Therefore, loads shall be pulled in line with the winch unless the winch is properly equipped with a fair lead and the operator is trained to pull loads at an angle.
- 5.9.14 The operator shall ensure that the vehicle supporting the winch is secured to avoid unintended movement.
- 5.9.15 The operator shall ensure that all rigging points comply with section 8.4, Rigging.

5.9.16 To ensure precise communication, an effective means of communication shall be established and used with all workers involved in the winching operations (see subsection 8.4.11).

5.9.17 Where wire rope clips are used to form eyes in wire rope, manufacturers' recommendations shall

be followed. If U-bolt clips are used and the manufacturers' recommendations are not available, Table 3 shall be used to determine the number and spacing of the clips in accordance with OSHA standard 1926.251 Table H-20. U-bolts shall be applied with the U section in contact with the dead end of the rope. All components shall be designed and rated for such purpose.

Table 3. Number and Spacing of U-Bolt Wire Rope Clips

Improved plow steel, rope diameter [inches(cm)]	Minimum number of clips		Minimum spacing [inches(cm)]
	Drop forged	Other material	
1/2 (1.3) or less	3	4	3 (7.6)
5/8 (1.6)	3	4	3-3/4 (9.5)
3/4 (1.9)	4	5	4-1/2 (11.4)
7/8 (2.2)	4	5	5-1/4 (13.3)
1 (2.5)	5	6	6 (15.2)
1-1/8(2.9)	6	6	6-3/4 (17.1)
1-1/4 (3.2)	6	7	7-1/2(19.1)
1-3/8 (3.5)	7	7	8-1/2(21.0)
1-1/2 (3.8)	7	8	9 (22.9)

6 PORTABLE POWER HAND TOOLS

6.1 General

6.1.1 The purpose of this section is to provide guidelines for arborists and other workers pertaining to the safe use and care of portable power hand tools.

6.1.2 Manufacturers' operating, maintenance, and safety instructions shall be followed unless modified by this standard.

6.1.3 Communications shall be established among arborists working aloft, either in a tree or from an aerial device, and arborists and other workers on the ground, before starting or otherwise using any portable power hand tools. The command "stand clear" from aloft and response "all clear" from the ground are terms that may be used for this purpose. Pre-arranged, two-way hand signals may also be used. Arborists and other workers returning to the work area shall be acknowledged by arborists aloft.

6.1.4 When a chain saw or power hand tool is carried aloft and is not in use, it shall be secured against falling.

6.1.5 Portable power hand tool operators shall communicate with other workers and ensure that they are clear of the equipment and work area.

6.2 Portable Electric Power Tools

- 6.2.1 The items contained in section 6.1 shall always be included in the review of this section.
- 6.2.2 Corded electric power tools shall not be used in trees or aerial devices near energized electrical conductors where there is a possibility of power tools or supply cords contacting the conductor.
- 6.2.3 All corded portable electric power tools shall be
- (a) equipped with three-wire cords having the ground wire permanently connected to the tool frame and a means for grounding the other end; or
 - (b) double insulated and permanently labeled as “double insulated”; or
 - (c) connected to power supplies by means of an isolating transformer or other isolated power supply.
- 6.2.4 Extension cords shall be maintained in safe condition. Exposed metal sockets shall not be used.
- 6.2.5 Arborists and other workers shall prevent cords from becoming entangled, damaged, or cut by blades and bits and shall avoid laying extension cords in water.

6.3 Chain Saws

- 6.3.1 The items contained in section 6.1 shall always be included in the review of this section.
- 6.3.2 Chain saws shall not be operated unless the manufacturer's safety devices are in proper working order. Chain saw safety devices shall not be removed or modified.
- 6.3.3 A stable body position shall be maintained when starting a chain saw.
- 6.3.4 **Drop-starting** a chain saw is prohibited. A chain saw shall be started with the chain brake engaged and the operator holding the saw firmly in a manner that minimizes movement of the saw when pulling the starter handle.
- 6.3.5 Chain saw engines shall be started and operated only when other arborists and workers are clear of the chain saw.
- 6.3.6 A chain saw shall be operated with the left hand and thumb gripped firmly around the forward handle and the right hand and thumb gripped firmly around the rear handle unless it is not practicable and the employer demonstrates that a greater hazard is posed by operating the chain saw that way in that particular situation.

- 6.3.7 Arborists shall be tied in and use a second means of being secured (i.e., **work-positioning lanyard** or second climbing line) when operating a chain saw in a tree. Using two work-positioning lanyards or both ends of a two-in-one work-positioning lanyard shall not be considered acceptable as two means of being secured when using a chain saw in a tree.

EXCEPTION

When the employer demonstrates that a greater hazard is posed by using a second means of being secured while operating a chain saw in that particular situation.

- 6.3.8 The chain brake shall be engaged or the engine shut off before setting a chain saw down.
- 6.3.9 When a chain saw is being carried more than two steps, the chain brake shall be engaged or the engine shut off. The chain saw shall be carried in a manner that will prevent operator contact with the cutting chain and the muffler.
- 6.3.10 The chain saw operator shall be certain of a stable body position before starting to cut. The chain saw shall not be used in a position or at a distance that could cause the operator to become off-balance, have insecure footing, or relinquish a firm grip on the saw.

6.4 Powered Pole Tools and Backpack Power Units

- 6.4.1 The items contained in section 6.1 shall always be included in the review of this section.
- 6.4.2 Only workers operating the equipment shall be within 10 feet (3.05 m) of the cutting head of a brush saw during operations.
- 6.4.3 Powered pole tools with poles made of metal or other conductive material shall not be used in operations where electrical hazards exist.

7 HAND TOOLS AND LADDERS

7.1 General

- 7.1.1 Correct hand tools and equipment shall be selected for the job.
- 7.1.2 Hand tools and equipment that have been made unsafe by damage or defect, including tools with loose or cracked heads or cracked, splintered, or weakened handles, shall not be used.
- 7.1.3 Workers shall maintain a safe working distance from other workers when using hand tools and equipment.

- 7.1.4 When climbing into a tree, arborists shall not carry hand tools and equipment in their hands unless the tools are used to assist them in climbing. Tools other than ropes or throwlines shall not be thrown into a tree or between workers aloft.
- 7.1.5 Arborist climbing lines or **handlines** should be used for raising and lowering hand tools and equipment. Arborists should raise or lower hand tools and equipment in a manner such that the cutting edge will not contact the arborist climbing line or handline.
- 7.1.6 Hand tools and equipment shall be properly stored or placed in plain sight out of the immediate work area when not in use.

7.2 Cant Hooks, Cant Dogs, Peaveys, and Tongs

- 7.2.1 The items contained in section 7.1 shall always be included in the review of this section.
- 7.2.2 **Cant hooks** should be firmly set before applying force.
- 7.2.3 Points of hooks shall be at least 2 inches (5 cm) long and kept sharp.
- 7.2.4 Arborists and other workers shall always stand uphill from rolling logs, and all workers shall be warned and in the clear before logs are moved.

7.3 Wedges, Chisels, and Gouges

- 7.3.1 The items contained in section 7.1 shall always be included in the review of this section.
- 7.3.2 **Wedges**, chisels, and gouges shall be inspected for cracks and flaws before use. Tools with damaged heads shall not be used.
- 7.3.3 Wedges and chisels shall be properly pointed and tempered.
- 7.3.4 Eye protection shall be used during impact operations.
- 7.3.5 Only wood, plastic, or soft-metal wedges shall be used while operating chain saws.
- 7.3.6 Wood-handled chisels should be protected with a ferrule on the striking end.
- 7.3.7 Wood, rubber, or high-impact plastic **mauls**, sledges, or hammers should be used when striking wood-handled chisels or gouges.

7.4 Chopping Tools

- 7.4.1 The items contained in section 7.1 shall always be included in the review of this section.
- 7.4.2 **Chopping tools** should not be used while working aloft.
- 7.4.3 Chopping tools shall not be used as wedges or used to drive metal wedges.
- 7.4.4 Chopping tools shall be swung away from the feet, legs, and body, using the minimum force practical for function and control.
- 7.4.5 When swinging tools such as grub hoes, mattocks, and axes, a secure grip, firm footing, and clearance of workers and overhead hazards shall be maintained.

7.5 Ladders

- 7.5.1 The items contained in section 7.1 shall always be included in the review of this section.
- 7.5.2 Ladders made of metal or other conductive material shall not be used where electrical hazards exist. Only wooden ladders (constructed in accordance with ANSI A14.1) or nonconductive ladders made of synthetic material equal to or exceeding the strength of wooden ladders shall be used.
- 7.5.3 Metal ladders used where no electrical hazard exists shall conform to ANSI A14.2.
- 7.5.4 All ladders shall be inspected before use and removed from service if found defective.
- 7.5.5 Cleats, metal points, skid-resistant feet, lashing, or other effective means of securing the ladder shall be used when there is danger of slipping.
- 7.5.6 Ladders shall not be used as bridges or inclined planes to load or handle logs or other material.
- 7.5.7 Ladders shall be supported while in storage to prevent sagging. Except when on mobile equipment, ladders should be stored under suitable cover, protected from the weather, and kept in a dry location away from excessive heat.
- 7.5.8 The third, or hinged, leg of a **tripod/orchard ladder** shall be braced or fastened when on hard or slick surfaces.
- 7.5.9 All ladders shall be used in accordance to the manufacturers' recommendations and shall not be altered in a way that contradicts those recommendations.

8 WORK PROCEDURES

8.1 Ropes and Arborist Climbing Equipment

- 8.1.1 A visual hazard assessment, including a root collar inspection, shall be performed prior to climbing, entering, or performing any work in a tree.
- 8.1.2 A second arborist, an arborist trainee, or other worker trained in emergency procedures shall be within visual or voice communication during arboricultural operations above 12 feet (3.65 m) that are not subject to the requirements of subsection 4.2.4.
- 8.1.3 Climbing lines used in a **split-tail** system and split-tails shall be terminated with an eye splice or a knot that interfaces appropriately with the connecting link. When using a carabiner without a captive eye, the termination selected shall maintain loading along the major axis. The connection between carabiners and terminated rope ends shall be compatible to limit the possibility of accidental disconnection or minor axis loading of carabiners.
- 8.1.4 Arborists shall inspect climbing lines, **worklines**, lanyards, and other climbing equipment for damage, cuts, abrasion, and/or deterioration before each use and shall remove them from service if signs of excessive wear or damage are found.
- 8.1.5 Arborist ropes, work-positioning saddles, and climbing equipment shall be approved by the manufacturer for use within the tree care industry.
- 8.1.6 Arborist saddles and lanyards used for work positioning shall not be altered in a manner that would compromise the integrity of the equipment.
- 8.1.7 Arborist climbing lines shall have a minimum diameter of 1/2 inch (12.7 mm) and be constructed from a synthetic fiber, with a minimum breaking strength of 5,400 pounds (24.02 kilonewtons [kN]) when new. Maximum working elongation shall not exceed 7 percent at a load of 540 pounds (2.402 kN). Arborist climbing lines shall be identified by the manufacturer as suitable for tree climbing.

EXCEPTION

In arboricultural operations not subject to regulations that supersede Z133, a line of not less than 7/16 inch (11 mm) diameter may be used, provided the employer can demonstrate it does not create a safety hazard for the arborist and the arborist has been instructed in its use. The line selected shall meet or exceed the standards for arborist climbing lines.

- 8.1.8 **Prusik loops**, split-tails, and work-positioning lanyards used in a climbing system shall meet the minimum strength standards for arborist climbing lines.

- 8.1.9 **Snap hooks** (rope snaps) used as part of a climber's work-positioning (suspension) system shall be self-closing and self-locking, with a minimum tensile strength of 5,000 pounds (22.24 kN).
- 8.1.10 Carabiners used as part of a climber's work-positioning (suspension) system shall be self-closing and self-double-locking and shall have a gate-locking mechanism that requires at least two consecutive, deliberate actions to unlock. Carabiners shall be capable of withstanding a 5,000-pound (22.24-kN) load along its major axis with the gate closed without breaking or distortion sufficient to release the gate.
- 8.1.11 Carabiners and snap hooks used as part of a climber's fall protection (work-positioning/suspension/fall-arrest system) shall not be linked together unless designed to do so and accepted by the manufacturer.
- 8.1.12 Load-rated screw links used as part of a climber's work-positioning (suspension) system shall have a minimum tensile strength of 5,000 pounds (22.24kN) and shall be securely tightened to ensure that they will not unintentionally open during use.
- 8.1.13 Splicing shall be done in accordance with cordage manufacturers' specifications.
- 8.1.14 Equipment used to secure an arborist in the tree or to an aerial device shall not be used for anything other than its intended purpose.

EXCEPTION
An arborist's climbing line may be used to raise and lower tools.
- 8.1.15 Rope ends shall be finished in a manner to prevent raveling.
- 8.1.16 Ropes and climbing equipment shall be stored and transported in such a manner to prevent damage through contact with sharp tools, cutting edges, gas, oil, or chemicals.
- 8.1.17 Arborist climbing lines shall never be left in trees unattended.
- 8.1.18 While working aloft, the climber shall have available a climbing line and at least one other means of being secured on his/her person at all times (example: an arborist climbing line and a work-positioning lanyard). Two means of being secured shall be used when the arborist determines that it is advantageous.
- 8.1.19 Hand saws should be taken by the climber/aerial device operator while working aloft. Hand saws aloft shall either have a scabbard or be of the folding type that covers the cutting teeth when closed.

- 8.1.20 The arborist shall be secured at all times while ascending the tree, including when using climbing spurs/gaffs. The arborist shall be tied in once the work begins and shall remain tied in until the work is completed and he/she has returned to the ground. The arborist shall be secured when repositioning the climbing line.
- 8.1.21 Climbing spurs shall have gaffs of the type and length suitable for the tree being climbed. Manufacturer's recommendations for inspection, maintenance, sharpening, and replacing worn gaffs shall be followed.
- 8.1.22 While ascending a ladder to gain access to a tree, the arborist shall not work from or leave the ladder until he/she is tied in or secured.
- 8.1.23 Hands and feet should be placed on separate limbs, if possible, and three points of contact should be maintained with the tree while climbing.
- 8.1.24 A **false crotch** and/or false-crotch redirect may be used at the discretion of the arborist in lieu of a natural crotch.
- 8.1.25 The tie-in position should be well above the work area so that the arborist will not be subjected to an uncontrolled pendulum swing in the event of a slip.
- 8.1.26 When a climber is working at heights greater than one-half the length of the arborist climbing line, a stopper knot shall be tied in the end of the arborist climbing line to prevent pulling the line through the **climbing hitch**.
- 8.1.27 Arborists working from a stem or **spar** without a suitable natural crotch shall select tie-in points or a tie-in method that positively prevents the climbing line from sliding down or up or off the stem during climbing operations. Placing a climbing line around a stem in an area without a lateral limb is not acceptable unless the climbing line is cinched or choked around the stem or runs through a double-wrapped or adjustable false crotch, which is secured/cinched around the stem. The tie-in point selected shall be able to withstand the forces being applied during the pruning/removal operation.
- 8.1.28 The non-working end of any work-positioning lanyard shall have a fixed termination (fixed stopper knot, eye splice, snap, carabiners, or other hardware) that does not permit the non-working end of the lanyard to advance through the friction device (friction hitch, cam-loaded ascender, frame loaded ascender) or shall be securely connected to a rated connection point on the climbing saddle.

8.2 Pruning and Trimming

- 8.2.1 Pruning should be conducted in accordance with the ANSI A300 (Part 1) standard.
- 8.2.2 The arborist in charge shall establish a safe work plan to manage the **drop zone**. Communications among arborists aloft and other workers on the ground shall be established before cutting and dropping limbs. The command “stand clear” from aloft and the response “all clear” from the ground are terms that may be used for this purpose. Pre-arranged, two-way hand signals may also be used. Arborists and other workers returning to the work area shall be acknowledged by arborists aloft.
- 8.2.3 Pole pruners and pole saws, when hung, shall be securely positioned to prevent dislodgment. Pole pruners or pole saws shall not be hung on electrical conductors or left in a tree unattended. Pole saws and pole pruners shall be hung so that sharp edges are away from the arborist and shall be removed when the arborist leaves the tree.
- 8.2.4 Scabbards or sheaths shall be used to carry hand saws when not in use. Folding saws, when not in use, shall be closed and hooked to the arborist saddle.
- 8.2.5 Pole tools used in line-clearance operations shall be constructed with fiberglass-reinforced plastic (FRP) or wooden poles meeting the requirements of OSHA 1910.269.
- 8.2.6 Limbs that cannot be safely controlled by hand or free-dropped shall have a separate rigging line tied to them to help control their fall. Rigging practices shall conform to requirements in section 8.4 of this standard.
- 8.2.7 Dry conditions and dead palm fronds present an extreme fire hazard. When dry conditions exist, arborists and other workers shall not smoke while working in or near dead palm fronds. All chain saws used under such conditions shall have mufflers and spark arresters in **good working condition**.
- 8.2.8 Palm frond skirts that have three years or more of growth shall be removed from the top down. Arborists performing this work shall be supported by an arborist climbing line and a false crotch. Arborists shall never attempt to remove skirts of three years or more by positioning themselves below work areas while being supported by a lanyard.
- 8.2.9 Cut branches, tools, and equipment shall be removed from trees upon completion of work.
- 8.2.10 If a climbing line is known to have been damaged while working aloft, the climber shall secure himself/herself with a work-positioning lanyard and shall immediately replace the damaged line. The ground crew shall keep the climbing line free of debris and obstructions, protect it from damage, and report any known damage to the arborist. The climber shall check his/her climbing line for damage while descending.

8.3 Cabling

- 8.3.1 Cabling should be conducted in accordance with the ANSI A300 (Part 3) standard.
- 8.3.2 Arborists and other workers on the ground shall not stand in the drop zone when a cabling system is being installed.
- 8.3.3 Tools used for cabling shall be carried in a bag, placed on a belt designed to hold such tools, or securely attached to a **tool lanyard** to prevent the tools from falling to the ground.
- 8.3.4 Arborists installing cabling systems in trees shall be positioned off to one side in order to avoid injury in case of cabling system failure that could occur when a block and tackle or a hand winch is released.
- 8.3.5 When installing or replacing a support system, the load shall be released onto the new support system in a slow and controlled manner to help prevent sudden or dynamic loading by using a ratcheting come-a-long or similar tool.
- 8.3.6 When a previously installed support system is to be removed or replaced, it shall not be removed until a new support system is installed to take the weight off of the previously installed system, or until a temporary support system has been installed to slacken the previously installed system.

8.4 Rigging

- 8.4.1 Arborists performing rigging operations shall inspect trees for their integrity to determine whether the trees have any visible defect that could affect the operation. If it is determined that the tree poses a risk of failure due to the forces and strains that will be created by the design of the rigging operation, an alternate plan shall be used.
- 8.4.2 Rigging points shall be assessed for their structural integrity by a qualified arborist. The rigging plan and the tree shall be considered relative to the forces being applied to any part of the tree, including branch attachments and anchoring roots, before a rigging point is chosen and established.
- 8.4.3 Arborists performing rigging operations shall be educated to understand and trained to estimate the potential forces at any point in the rigging system being used. The system components shall comply with **working-load limits** relative to the operation and the maximum potential forces.
- 8.4.4 Careful consideration shall be given to the potential for additional forces resulting from the specific influences of rigging design, rope angles, and the number of lines and/or line parts that will act on any rigging or anchor point.

- 8.4.5 A qualified arborist shall ensure that load ratings shown on the rigging equipment or provided by the manufacturer for all ropes, connecting links, and rigging equipment are observed in all rigging operations. Rigging equipment shall be chosen for the specific task based on working-load limits and design specifications. If carabiners are used in a rigging system, loading of the gate and/or the minor axis of a carabiner shall be prevented.
- 8.4.6 The number of connecting links used for connecting components of a rigging system shall be minimized when possible. Arborists shall ensure that shackles, screw links, and other connecting links interface properly and are in compliance with manufacturers' recommendations.
- 8.4.7 All equipment used for rigging operations shall be in good working condition. Equipment that has been damaged or overloaded shall be removed from service.
- 8.4.8 When the potential exists for rigging equipment to be confused with climbing equipment, the equipment shall be clearly marked to indicate their different purposes.
- 8.4.9 When establishing a rigging point horizontally distant from the parent limb or main tree stem, the arborist should consider the need to provide additional support to help disperse the force of the proposed rigged load.

Options may include

- (a) Use of a **backstay** to support the load-bearing rigging point by placing an appropriately rated rope from the limb used as the load-bearing rigging point back to a higher point on the main trunk of the tree or other higher and suitable limb; or
 - (b) Installation of an additional and separate rigging system that utilizes supporting members, other than those already in use by the primary lowering point, in an effort to have both rigging systems share the load force.
- 8.4.10 Arborists working aloft (either climbing the tree or from an aerial device) shall establish a communication system with arborists and other workers on the ground.
 - 8.4.11 A method of verbal, audible, or visual communication shall be discussed and established during the job briefing prior to the start of removal or rigging operations. The verbal, audible, or visual communication system shall use an established command and response system (see example) or pre-arranged, two-way hand signals. The communication method shall be clearly understood and used during all rigging operations.

Example (but not limited to):

Command:

- Stand clear!

Response:

- All Clear!
- Underneath!

or

- No!

- 8.4.12 Within the work area, a drop zone shall be established prior to the start of rigging operations. Workers not directly involved in the rigging operation shall stay out of the pre-established drop zone until it has been communicated by a qualified arborist or **qualified arborist trainee** directly involved in the rigging operation that it is safe to enter. Workers shall be positioned and their duties organized so that the actions of one worker will not create a hazard for any other worker.
- 8.4.13 Only qualified arborists or qualified arborist trainees directly involved in the operation shall be permitted in the drop zone when a load is being suspended by the rigging system.
- 8.4.14 **Taglines** or other means may be used to help control and handle suspended loads.
- 8.4.15 Arborists working aloft shall position themselves so as to be above or to the side of the piece being rigged and out of the path of movement of the piece when it has been cut. Climbers shall have an escape plan prepared.
- 8.4.16 Climbers and their climbing systems shall not make contact with moving or swinging parts of the rigging system when making a release cut or when the load is moving. Rigging systems shall not compromise any part of the climbing system.
- 8.4.17 Steps shall be taken to prevent spars from splitting or tearing during the rigging operation, and climbers shall take steps to avoid trapping, pinning, or entangling themselves in the system should the tree split or the rigging fail. Load binders are one possible means of preventing splitting.
- 8.4.18 A hand saw shall be with a worker aloft to make or finish cuts.

8.5 Tree Removal

- 8.5.1 Before beginning any tree removal operation, the chain saw operator, equipment operator, and/or crew leader shall carefully consider relevant factors pertaining to the tree and site and shall take appropriate actions to ensure a safe removal operation. Factors to include may be, but are not limited to, tree decay, tree lean, and wind (see Annex C.3, Manual Tree Felling Procedure, for a more inclusive list).

- 8.5.2 The crew leader shall assess the number of workers necessary for tree removal operations and plan the work so that operations do not conflict in a hazardous manner.
- 8.5.3 Workers not directly involved in the removal operation shall be clear of the drop zone, where practicable, beyond the length of the tree.
- 8.5.4 In **manual tree felling** operations, non-involved workers shall be beyond twice the height of the tree or trunk being removed.

EXCEPTION

This requirement does not apply in the presence of site restrictions, such as waterways or cliffs. Other arborists and workers shall be beyond a tree's striking range and at a distance as close to twice the tree's height as practicable.

- 8.5.5 Workers returning to the drop zone shall not enter until the worker aloft has acknowledged that it is safe to do so.
- 8.5.6 A planned retreat/escape path for all workers within the drop zone shall be prepared before piecing down or manual felling any standing tree or tree parts.
 - 8.5.6.1 During manual tree felling, the preferred retreat/escape path for the chain saw operator is 45 degrees on either side of a line drawn opposite the intended direction of the fall.
 - 8.5.6.2 The retreat/escape path shall be cleared to the extent practical of obstructions and objects that would hinder retreat.
 - 8.5.6.3 The chain saw operator shall use this path for egress once the felling cuts have been completed or the tree begins to fall.
 - 8.5.6.4 Other involved workers shall have and use retreat/escape paths that do not hinder other retreating workers or expose any involved workers to increased hazard.
- 8.5.7 When it is necessary to use rigging to shorten or remove branches or to block down pieces of the tree, the arborist shall consider whether the tree can withstand the strain of the lowering procedures. If the arborist determines that the tree cannot withstand the strain of the lowering procedures, other means of removing the tree shall be implemented.
- 8.5.8 When there is a danger that the tree pieces or tree being removed may fall in the wrong direction and damage property, wedges, block and tackle, rope, wire cable (except where an electrical hazard exists), or other appropriate devices shall be used to control the direction of fall. All limbs shall be removed to a height and width sufficient to allow the tree parts or tree to fall clear of hazards, such as wires and/or other objects in the vicinity.

- 8.5.9 Ground workers involved in handling rigging lines shall not be underneath dynamic or suspended loads and should be out of the drop zone when practicable.
- 8.5.10 Ground workers handling taglines used during manual tree felling shall be outside of the striking distance of the tree, preferably 1.5 times the height of the tree away, or further when practicable.
- 8.5.11 Rigging equipment and its connecting links shall be inspected immediately before use and removed from service if found to be defective.
- 8.5.12 During manual tree felling operations, notches shall be used on all trees and trunks greater than 5 inches (12.7 cm) in diameter at breast height.
- 8.5.13 When manual tree felling, notches and **back cuts** shall be made at a height that enables the chain saw operator to safely begin the cut, control the tree or trunk, and have freedom of movement toward a retreat/escape path.
 - 8.5.13.1 The two cuts that form the notch shall meet at a point called the apex and shall not cross that point or go beyond the point where they meet.
 - 8.5.13.2 The notch cut used shall be a **conventional notch**, an **open-face notch**, or a **Humboldt notch**.
 - 8.5.13.3 Notches shall be 45 degrees or greater and large enough to guide the fall of the tree or trunk.
 - 8.5.13.4 Notch depth should not exceed one-third the diameter of the tree.
 - 8.5.13.5 Saw cuts made to form the notch and back cut shall leave suitable amounts of **hinge** wood to adequately control the directional fall of the tree.
 - 8.5.13.6 With a conventional notch or Humboldt notch, the back cut shall be 1 to 2 inches (2.5 to 5 cm) above the apex of the notch to provide an adequate platform to prevent kickback of the tree or trunk. With an open-face notch (greater than 70 degrees), the back cut should be at the same level as the apex of the notch.
- 8.5.14 The hazard of **barber chair** should be considered when cutting trees under tension. Steps to prevent the sudden splitting of trunk wood should be taken. Preventive steps may include, but are not limited to, various back cut methods; wrapping a ratchet strap, rope, or chain around the tree above the notch and back cut area; or relieving the tension in or on the tree by slackening pull ropes or removing upper parts of the tree prior to felling.

- 8.5.15 Before making the back cut, there shall be a command such as “stand clear” from the arborist operating the chain saw and a response such as “all clear” from the workers supporting the removal operation. Pre-arranged, two-way hand signals may also be used. Only designated persons shall give such signals. All non-involved workers in the vicinity shall be out of range when the tree or trunk falls.
- 8.5.16 When the tree or trunk begins to fall, the worker at the base of the tree shall immediately move a safe distance away from the tree or trunk using the retreat/escape path.
- 8.5.17 During manual tree felling operations, involved workers shall keep visual contact with the tree or trunk until it is on the ground.

EXCEPTION

When the tree or trunk begins to fall, the worker at the base of the tree shall immediately move a safe distance away from the tree or trunk using the retreat/escape path.

- 8.5.18 Workers shall not approach mechanical tree removal or mechanical clearing operations, such as with a rotary or flail mower, tree shear, feller-buncher, or boom-mounted saws, until all cutting has halted and the equipment operator has acknowledged that it is safe to do so.

8.6 Brush Removal and Chipping

- 8.6.1 Traffic and pedestrian control around the jobsite shall be established prior to the start of chipping operations along roads and highways (see section 3.2, Traffic Control).
- 8.6.2 Brush and logs shall be placed in such a way as to reduce risk in the work area.
- 8.6.3 To prevent an entanglement hazard, loose clothing, climbing equipment, body belts, arborist saddles, lanyards, or gauntlet-type gloves (for example, long-cuffed lineman's or welder's gloves) shall not be worn while operating chippers.
- 8.6.4 Personal protective equipment shall be worn when in the work area of chipping operations in accordance with section 3.4, Personal Protective Equipment, of this standard.
- 8.6.5 Only persons trained in safe chipper operation may operate chippers. Training shall include, but is not limited to, inspection, starting, stopping, feeding, and shutdown. Training shall be provided for each type of chipper being used.
- 8.6.6 Maintenance shall be performed only by those persons authorized by the employer and trained and qualified to perform such operations in accordance with manufacturers' specifications (see Annex C, General Safety Procedures That Apply to All Tree Work).

- 8.6.7 Brush and logs shall be fed into chippers from the side of the feed table center line, butt or cut end first, and the operator shall immediately turn away from the feed table when the brush is taken into the rotor or feed rollers. Chippers should be fed from the curbside whenever practical.
- 8.6.8 When feeding a chipper during roadside operations, the operator shall do so in a manner that prevents him/her from stepping into traffic or being pushed into traffic by the material that is being fed into the chipper.
- 8.6.9 The brush chipper discharge chute or cutter housing cover shall not be raised or removed while any part of the chipper is turning or moving. Chippers shall not be used unless a discharge chute of sufficient length or design is provided that prevents personal contact with the blades (see Annex C, General Safety Procedures That Apply to All Tree Work).
- 8.6.10 Foreign material, such as stones, nails, sweepings, and rakings, shall not be fed into chippers.
- 8.6.11 Small branches shall be fed into chippers with longer branches or by being pushed with a long stick or tool designed for such use to prevent body parts from entering the infeed hopper.
- 8.6.12 Hands or other parts of the body shall not be placed into the infeed hopper. Leaning into or pushing material into infeed hoppers with feet is prohibited.
- 8.6.13 While material is being fed into the chipper infeed hopper chute, pinch points continually develop within the material being chipped and between the material and machine. The operator shall be aware of this situation and respond accordingly.
- 8.6.14 When using a winch in chipper operations, the operator shall ensure that the winch line is properly stored before initiating chipper operations.
- 8.6.15 Refer to section 5.3, Brush Chippers, for additional information.

8.7 Limbing and Bucking

- 8.7.1 Work plans for limbing and **bucking** operations shall be communicated to all workers in a job briefing before work begins.
- 8.7.2 When more than one worker is limbing or bucking a tree, each shall be positioned and their duties organized so that the actions of one worker will not create a hazard for any other worker.
- 8.7.3 Before bucking or limbing wind-thrown trees, precautions shall be taken to prevent the root ball or butt log from striking a worker.

- 8.7.4 Chain saws should be operated away from the vicinity of the legs and feet. Natural barriers, such as limbs between the saw and the body, should be employed where possible, while ensuring proper balance. While operating a chain saw, the preferred working position is on the uphill side of the work.
- 8.7.5 The worker shall make sure of firm footing before and during limbing and bucking. The worker shall not stand on loose chunks or logs that will roll when the log being bucked is sawed off.
- 8.7.6 Trees, limbs, or saplings under tension shall be considered hazardous. Appropriate cutting techniques and precautions shall be followed.
- 8.7.7 When necessary to prevent rolling, logs shall be blocked with wood or other suitable material.
- 8.7.8 Wedges should be used as necessary to prevent binding of the guide bar or chain when bucking trunks of trees.
- 8.7.9 Cant hooks or peaveys should be used as an aid in rolling large or irregular logs to complete bucking.
- 8.7.10 If mechanized equipment is to be used, the equipment operator shall establish an effective means of communication with other workers (see subsection 8.4.11).
- 8.7.11 Workers shall not approach mechanized equipment operations until the equipment operator has acknowledged that it is safe to do so.

8.8 Pesticide Application

- 8.8.1 Pesticide applicators shall obtain and remain current with all licensing/certification requirements as required by the appropriate state regulatory authority prior to using pesticides.
- 8.8.2 Pesticide applicators shall follow all applicable laws and/or regulations pertaining to pesticide use or handling.
- 8.8.3 The applicator shall follow label instructions in regard to pesticide applications.
- 8.8.4 Personal protective equipment shall be properly fitted, cleaned, maintained, and stored. Proper use of personal protective equipment as specified on the product label will reduce the risk of pesticide exposure to the applicator.
- 8.8.5 Personal protective equipment shall not be stored with pesticides.

- 8.8.6 Employee training shall be provided in the recognition of hazardous substances, proper handling, and emergency procedures in the event of a spill or accidental poisoning, as required by the OSHA 1910.1200 Hazard Communication regulations.
- 8.8.7 Material Safety Data Sheets (MSDS) for all products in inventory shall be freely available to all employees.
- 8.8.8 The applicator shall follow pesticide label instructions in regard to laundering his/her clothing.
- 8.8.9 The applicator should shower or bathe at the end of each workday.
- 8.8.10 The employer shall provide a clean water source at the worksite, which may be used for emergency personal decontamination. Precautions shall be taken to prevent contamination of the clean water source. Drinking water and decontamination water shall be kept in separate containers.
- 8.8.11 The applicator shall not direct a solid spray column into contact with electrical conductors.
- 8.8.12 Pesticides shall be stored in their original container or a clearly marked service container.
- 8.8.13 Pesticides shall be stored in locked compartments.
- 8.8.14 Pesticide storage areas shall meet or exceed all applicable state and local regulations.
- 8.8.15 An emergency action plan, including spill response materials and procedures, shall be available where pesticides are stored, transported, or handled.

8.9 Mixing Pesticides

- 8.9.1 Pesticides shall be mixed in an area that is outdoors or in a well-ventilated, illuminated, enclosed area.
- 8.9.2 Devices used for mixing and measuring pesticides shall be specifically designated and marked for pesticide use and shall be used for no other purpose.

8.10 High-Pressure Air-Excavation Equipment

- 8.10.1 Personal protective equipment shall be required for the operator and all crew members within the work area and shall include hard hat with attached face shield, hearing protection, eye protection, and gloves. Additionally, long pants, a long-sleeved shirt, and/or coveralls shall be worn.
- 8.10.2 Respiratory protection should be worn when conditions warrant. When used, respiratory protection shall be in accordance with the OSHA 1910.134 Respiratory Protection Standard.

- 8.10.3 A proper work area shall be identified; measures shall be taken to keep non-involved individuals clear of the work area.
- 8.10.4 The compressor operator shall understand and follow all operating instructions for the compressor.
- 8.10.5 The air hose shall be properly attached and secured to the compressor prior to starting the compressor.
- 8.10.6 Body parts shall not be placed in front of air jets.
- 8.10.7 When the operator is finished, the air line shall be depressurized prior to uncoupling the air hose.

8.11 Fertilization/Soil Management

- 8.11.1 All products shall be used in accordance with manufacturers' recommendations.
- 8.11.2 Fertilizers shall be stored away from ignition sources and separate from petroleum products and pesticides.
- 8.11.3 Smoking shall be prohibited in the fertilizer storage area.

ANNEX A
(Informative)
Glossary of Terms for ANSI Z133

NOTE—The numbers in parentheses after these terms are cross-references to the section in the standard where the term is first used in a major context. See index for other uses of these terms in the standard.

aerial device (4.1.3): Any one of the following types of vehicle-mounted apparatus used to elevate personnel to work positions aloft:

- extensible boom platform
- aerial ladder
- articulating boom platform
- vertical tower
- a combination of any of the above, as defined in ANSI A92.2

apex (8.5.13.1): The point at which two saw cuts meet to form a notch.

applicator (5.4.3): A qualified person engaged in the application of materials such as, but not limited to, pesticides, growth regulators, and fertilizers.

approved (3.4.6): Acceptable to the federal, state, or local jurisdiction having enforcement authority.

approved containers (3.5.3): Containers having a spring-closing lid and spout cover designed to safely relieve internal pressure when subjected to fire exposure.

arboriculture (1.1): The art, science, technology, and business of utility, commercial, and municipal tree care.

arborist (1.2): An individual engaged in the profession of arboriculture.

arborist climbing line (5.7.13): A line designated to support the climber while aloft in a tree or attached to a crane, constructed according to specifications outlined in subsection 8.1.7.

arborist saddle (5.7.13): A body-holding device that fastens around the waist and around the thighs with or without an integrated rigid seat; used by arborists in conjunction with other components for work positioning and suspension in trees (a.k.a. tree saddle, sit harness).

authorized (5.1.5): Designated by the entity that has care, custody, and control of the unit.

back cut (8.5.13): The cut made in a tree limb or trunk on the side opposite the intended direction of fall.

backstay (8.4.9): A rope or cable that is set to share the load on a spar, limb, jib, pole, or other load-bearing member.

barber chair (8.5.14): Dangerous condition created when a tree or branch splits upward vertically from the back cut (a.k.a. slab up).

blind pick (5.7.12): A work situation where the qualified arborist or the load is not in full view of the qualified crane operator.

boom-supported elevating work platform (5.2.34): A self-propelled, integral-chassis aerial platform that can be positioned completely beyond the base and used to position personnel, along with their necessary tools and materials, at work locations. Aerial platforms are power-operated, and primary functions, including drive, are controlled from the platform. Such aerial platforms are intended to be occupied when driven.

brush hog (5.8.3): A heavy-duty rotary mower, normally pulled by a farm-type tractor, used for cutting and mulching brush.

bucket (5.2.10): A basket-type platform approximately 4 feet (1.22 m) high, which is attached to the end of the upper boom on an aerial device, providing a work platform for working aloft.

bucking (8.7.1): The act of sawing trees, limbs, or both, into smaller sections once they are on the ground.


cant hook (7.2.2): A long-handled lever fixed with a blunt metal end to handle logs; includes a swinging, metal hook opposing the blunt end to create leverage.

carabiner (8.1.3): A connector generally composed of a trapezoidal or oval-shaped body with a closed gate or similar arrangement that may be opened to receive an object and, when released, automatically closes to retain the object.

chopping tool (7.4.2): A wooden-, fiberglass-, or steel-handled tool with a sharp, single- or double-edged steel head or blade mounted to it that is used to cut or split wood (for example, an ax or machete).

climbing hitch (8.1.26): A hitch used for securing a tree climber to the climbing line, permitting controlled ascent, descent, and work positioning. Examples of climbing hitches include, but are not limited to, the tautline hitch, Blake's hitch, and the Prusik hitch.

conventional notch (8.5.13.2): A directional felling cut in the side of a tree, facing the intended direction of fall and consisting of a horizontal face cut and an angle cut above it, creating a notch of approximately 45 degrees (see drawing).



crew leader (5.7.10): The qualified arborist designated as the individual in charge of a specific job or group of workers.

crotch (8.1.24): (n.) Branch union; the angle formed by two branches in the tree. (v.) To place a line through a branch union.

deadman control (5.8.3): A safety switch, electrical or mechanical, that deactivates the equipment's function when released by the operator.

de-energizing (4.1.4): Freeing from any electrical connection to a source of potential difference and from electric charge; not having a potential different from that of the earth.

dielectric (3.4.4): Nonconductive of electrical current.

direct contact (4.1.3[b]): A direct contact is made when any part of the body touches or contacts an energized electrical conductor.

direct supervision (3.1.3): Direct supervision occurs when a qualified arborist or a qualified arborist supervisor is physically present on the jobsite.

drop-starting (6.3.4): The act of starting a chain saw by pushing the saw away from the body with one hand while simultaneously pulling on the starter cord handle with the other.

drop zone (8.2.2): Area beneath workers aloft involved in arboricultural operations and/or where the potential exists for struck-by injuries from falling objects.

electrical conductor (3.4.4): Any overhead or underground electrical device capable of carrying an electric current, including communications wires and cables, power lines, and other such fixtures or apparatus.

electrical hazard (4.1.2): An object or situation that poses risk of injury or death due to direct or indirect contact with an electrical conductor. Where unguarded, energized electrical conductors are present, specific minimum approach distances based on the arborist's or worker's level of training, as set forth in this standard, shall be followed.

employer (1.3): A person or entity engaged in a business or work activity who has employees working at his/her (their) direction, or the designated representative of this person or entity.

electrical system owner/operator (4.1.4): An organization that operates or controls the trans-

mission and/or distribution of electric power through electrical conductors.

false crotch (8.1.24): A system, other than a natural crotch, used to support an arborist climbing line.

good working condition (8.2.7): A term describing a piece of equipment that has no mechanical defects, has all guards in place, and is operated as intended by the manufacturer.

grounded (4.1.3[a]): A system, circuit, or apparatus provided with a ground(s) for the purposes of establishing a ground return circuit and for maintaining its potential at approximately the potential of earth.

ground fault (4.1.3[d]): Any undesirable current path from a current-carrying conductor to ground.

handline (7.1.5): A length of rope designated as a tool to leverage, lift, and hold tools, equipment, wood, or other objects; the proper rope strength is specified for each particular use.

hinge (8.5.13.5): Strip of uncut wood fibers created between the face cut or notch and the back cut that helps control direction in tree felling or limb removal (a.k.a. holding wood).

Humboldt notch (8.5.13.2): A directional felling cut in the side of a tree, facing the intended direction of fall and consisting of a horizontal face cut and an angled cut below it, creating a notch of approximately 45 degrees (see drawing). A Humboldt cut is usually reserved for larger trees on steep slopes.



indirect contact (4.1.3[b]): Indirect contact is made when any part of the body touches any conductive object, including tools, tree branches, trucks, equipment, or other objects, that is in contact with an energized electrical conductor. Such contact can also be made as the result of communication wires and cables, fences, or guy wires being accidentally energized.

job briefing (3.1.4): The communication of at least the following subjects for arboricultural operations: hazards associated with the job, work procedures involved, special precautions, electrical hazards, job assignments, and personal protective equipment.

kilovolt, kV (Tables 1 and 2): The term for 1,000 volts, abbreviated as kV. Higher voltages are generally given as kilovolts. Examples: 12.5 kV (12,500 volts) and 19.9 kV (19,900 volts).

kilonewton, kN (8.1.7): A measurement of force, abbreviated as kN equal to 224.8 pounds. Example: 24.02 kilonewtons equals 5,400 pounds.

ladder (4.2.13): A two-, three-, or four-legged structure that utilizes vertical side legs with cross sections uniformly placed between the side legs to be used as steps; available in wood, aluminum, or fiberglass; used to ascend to and descend from a height. Also see *tripod/orchard ladder*.

lanyard (5.2.8): A component of a climbing system consisting of a flexible line of rope, wire rope, or a strap that generally has a connector at each end for connecting the body support to a fall arrester, energy absorber, anchorage connector, or anchorage.

leg protection (3.4.10): Personal protective equipment intended to reduce the risk of injury to the legs during chain saw operations.

line clearance (4.1.4): The pruning, trimming, repairing, maintaining, removing, treating, or clearing of trees or the cutting of brush (vegetation management) that is within 10 feet (3.05 m) of electric supply lines and equipment; vegetation management work performed by qualified line-clearance arborists or qualified line-clearance arborist trainees for the construction or maintenance of electric supply lines and/or the electric utility right-of-way corridor.

load radius (5.7.13.8): The horizontal distance from the axis of rotation of the crane to the center of the vertical load rope or tackle with a load applied.


manual tree felling (8.5.4): The removal of a tree or tree trunk by an arborist from the ground by the incorporation of a notch and back cut.

maul (7.3.7): A heavy hammer, sometimes made with a single edge; used to drive wedges or split wood.

minimum approach distance (4.1.4): Safe working distances from overhead electrical conductors as defined in Tables 1 and 2 of this standard.

mitigate (4.1.4): To lessen or make less severe a hazardous condition or dangerous situation.

open-face notch (8.5.13.2): A directional felling cut in the side of the tree, facing the intended direction of fall and consisting of two cuts that create a notch greater than 70 degrees (see drawing).



outrigger (4.1.3[d]): Built-in device used to stabilize cranes, aerial devices, and similar equipment.

phase (4.1.3[b]): Any current-carrying conductor that has an electric potential other than ground (ground is assumed to be 0 volts).

phase-to-ground (4.1.3[b]): The electric potential (voltage) between a conductor and ground.

phase-to-phase (4.1.3[c]): The electrical potential (voltage) between two conductors, each having its own electric potential relative to ground.

primary conductor (4.2.4): Any conductor, including aluminum, copper, or aluminum conductor steel-reinforced (ACSR), that is bare, covered, or insulated, with a nominal voltage above 750 volts.

proximity (3.4.4): An area within 10 feet (3.05 m) of energized overhead electrical conductors rated 50 kV phase-to-phase or less. For overhead electrical conductors rated more than 50 kV phase-to-phase, the distance is increased 4/10 inch (10 mm) for each additional kV.

Prusik loop (8.1.8): An endless loop of rope used to fashion a Prusik knot. The endless loop may be spliced or knotted with, at minimum, a double fisherman's knot.

qualified arborist (3.1.3): An individual who, by possession of a recognized degree, certification, or professional standing, or through related training and on-the-job experience, is familiar with the equipment and hazards involved in arboricultural operations and who has demonstrated ability in the performance of the special techniques involved.

qualified arborist trainee (8.4.12): An individual undergoing on-the-job training under the direct supervision of a qualified arborist. In the course of such training, the trainee becomes familiar with the hazards and equipment involved in arboricultural operations and demonstrates ability in the performance of the special techniques involved.

qualified crane operator (5.7.3): An individual who

- has demonstrated proficiency to operate the type and capacity of equipment he/she operates;
- is familiar with the equipment and hazards involved with arboriculture crane operations and has demonstrated proficiency in performing the special techniques involved; and
- where applicable, meets federal, state, or local requirements for licensure or training.

qualified line-clearance arborist (4.1.4): An individual who, through related training and on-the-job experience, is familiar with the equipment and hazards in line clearance and has demonstrated the ability to perform the special techniques involved. This individual may or may not currently be employed by a line-clearance contractor.

qualified line-clearance arborist trainee (4.2.3): An individual undergoing line-clearance training under the direct supervision of a qualified line-clearance arborist. In the course of such training, the trainee becomes familiar with the equipment and hazards in line clearance and demonstrates ability in the performance of the special techniques involved.

qualified personnel (5.1.5): An individual who, by reason of training and experience, has demonstrated the ability to safely perform assigned duties and, where required, is properly licensed in accordance with federal, state, or local laws and regulations.

quick-acting connector (5.2.24): Hose connectors in a hydraulic or pneumatic system designed to allow rapid connection or disconnection without leakage when the system is pressurized.

saddle, arborist: See *arborist saddle*.

secured (object) (5.1.6): Made firm or tight; fastened. Example: The load is secured to the truck.

secured (person) (5.2.18): When an arborist is safeguarded from unintended movement by utilizing a climbing system that is attached to the arborist and connected to a tree or other stable support. Examples of being secured include, but are not limited to, (a) being tied in, (b) using a work-positioning lanyard, (c) being on belay, and (d) ascending the arborist climbing line using the footlock technique while utilizing a Prusik loop or ascenders.

shall (1.4): As used in this standard, denotes a mandatory requirement.

shock-load (5.7.8): The force exerted by a falling or moving object on the structure supporting it, which is greater than the weight of the object (a.k.a. dynamic load).

should (3.1.3): As used in this standard, denotes an advisory recommendation.

signal person, designated (5.7.10): A qualified person assigned to monitor the crane operation and maintain appropriate communication with the qualified crane operator.

snap hook (8.1.9): Commonly called a self-locking or double-locking rope snap. The locking type (required by this standard for climbing) has a self-closing, self-locking gate that remains closed and locked until intentionally opened by the user for connection or disconnection. A captive eye is an integral part of a snap hook but is independent of the hook and gate portion.

spar (8.1.27): A standing trunk or main stem of a tree without a crown and lateral limbs.

split-tail (8.1.3): Separate, short length of rope used to tie the friction hitch in a climbing system.

spotter (5.2.33): A person within voice and visual communication distance of the driver and located in a position to view the area in which the vehicle (unit) is backing to help ensure that the backing operation is, and will remain, safe.

step potential (4.1.3[e]): The voltage between the feet of a person standing near an energized grounded object. It is equal to the difference in voltage, given by the voltage distribution curve, between two points at different distances from the electrode. A person could be at risk of injury during a fault simply by standing near the grounding point.

suspended (load) (5.7.7): Any attached load held off the ground and against the force of gravity by the crane.

tagline (8.4.14): A rope/line used to control the swing of a limb being removed; a line used to control the direction or fall of a tree or limb being removed.

temporary traffic control zone (3.2.2): An area of highway, street, or road where road user conditions are changed by the use of temporary traffic control devices.

testing (4.1.4): To determine the presence of electricity.

tied in (5.7.13): The term that describes an arborist whose climbing line has been run through a natural or false crotch attached to an arborist's saddle and completed with a climbing hitch or mechanical device, permitting controlled movement and work positioning.

tool lanyard (8.3.3): Short line or strap used to secure a tool while working aloft.

tripod/orchard ladder (7.5.8): A three-legged ladder that utilizes the third leg to form a tripod to stabilize itself among orchard trees and/or shrubs. It is recommended for use on turf for better stability and to avoid slippage of the legs. Not recommended for use on hard surfaces.

volt (4.2.4): A unit of electric potential difference between two points. Lower-voltage systems are generally expressed in terms of volts; for example, 120 volts or 240 volts.

wedge (7.3.2): A piece of material with two sides meeting at an angle; used to raise or split objects by applying a driving force, such as with a hammer.

wheel chock (5.2.4): Wedge-shaped block manufactured or employer approved to prevent unintentional movement of vehicle. Wheel chocks are placed in front of or in back of a vehicle's tires or tracks. If necessary, the chocks can be placed both in front and in back of the tires or tracks.

worker (1.2): An individual involved in an arboricultural operation, such as ground operations, equipment operations, and removal operations.

working-load limit (8.4.3): The working load that must not be exceeded for a particular application as established by a regulatory or standards-setting agency (see working load under Additional Terms, below).

workline (8.1.4): Rope used for lifting, lowering, or guiding limbs or equipment, or both, into or out of the tree.

work-positioning lanyard (6.3.7): A component of a climbing system consisting of a flexible line of rope or a strap that generally has a connecting link at each end and may incorporate a knot or mechanical device to allow for adjustability. This line or strap is designed to be used under tension to support an arborist or other worker on an elevated surface, such as a tree limb, and allow him or her to work with both hands free. Correct use of a work-positioning lanyard demands the lanyard be attached from one side D-ring of the saddle (harness), around the anchorage, to the opposite side D-ring of the saddle. Both ends of the lanyard may also be attached to the center attachment point of the saddle. Arborists shall not attach both ends of the lanyard to the same side D-ring of the saddle.

Additional Terms

ascender: A mechanical device used for climbing rope.

belay: Roping technique, managed by the ground person, to safeguard the arborist while climbing.

dbh: Acronym for diameter at breast height; diameter of a tree measured at 4.5 feet (1.3 m) above ground.

electric supply: Conductors used to transmit electric energy and their necessary supporting or containing structures. Signal lines of more than 400 volts are always supply lines, and those of less than 400 volts are considered as supply lines if so run and operated throughout.

energy (shock) absorber: A component of a climbing system whose primary function is to dissipate energy and limit deceleration forces that the system imposes on the body during fall arrest.

fall-arrest lanyard: A rope or strap designed to be used with a full-body harness to limit maximum arresting force on a climber to 1,800 pounds (8 kN) in a fall.

false crotch for rigging: A pulley, block, sling, lashing, or metal ring affixed to a tree's leader or limb, through which a load line is passed, to lower or raise limbs or equipment.

footlock: To climb up a suspended rope by pulling with the hands and arms and pushing upward with the feet. The loose end of the rope is wrapped under the middle and over the top of one foot and is locked in place with pressure from the other foot.

friction point: The point at which the rope surface of the climber's hitch rubs against the climbing line.

guarded: Covered, fenced, enclosed, or otherwise protected by suitable covers or casings, barrier rails or screens, mats, or platforms that have been designed by the electrical system owner/operator to minimize the possibility of dangerous approach or accidental contact by persons or objects under normal conditions. Also see unguarded.

Prusik knot: A sliding friction knot, as in a work-positioning lanyard.

unguarded: Not guarded from approach or contact with electrical conductors.

working load: Limiting load values derived from the minimum breaking strength of a cord or rope divided by the design factor. For example, given a minimum breaking strength of 10,000 pounds (44.48kN) and a design factor of 10:

$$10,000/10 = 1,000 \text{ (working load, in pounds)}$$

Or, given a minimum breaking strength of 10,000 pounds (44.48 kN) and a design factor of 5:

$$10,000/5 = 2,000 \text{ (working load, in pounds)}$$

The recommended design factor for personal fall protection components, such as fall arrest, fall restraint, work positioning, and suspension cordage and connecting links, etc., is a minimum of 10:1.

The recommended design factor for synthetic rigging components, such as rope, slings, cordage, etc., is a minimum of 5:1.

The recommended design factor for metal rigging components, such as wire rope, metal connecting links, etc., is a minimum of 3:1.

work-positioning system: An arborist climbing system designed to be used under tension to support the arborist or other worker on an elevated vertical surface, such as a tree limb, and allow him/her to work with both hands free.

ANNEX B
(Informative)
Recommended Guidelines for Standard Performance and Safety Training for
Qualified Line-Clearance Arborists/Qualified Line-Clearance Arborist Trainees
and Qualified Arborists/Qualified Arborist Trainees

NOTE: The content of this training outline is generic and may be customized to achieve equivalent levels of safe practice by substituting or, where deemed appropriate to the circumstances, omitting portions of this outline. Use or nonuse of training aids that may be available shall not be evidence of noncompliance with this standard or annex.

B.1 GENERAL REQUIREMENTS

Specific training in the area of individual expertise and work required of a qualified line-clearance arborist or qualified arborist should be provided by the employer and documentation of training retained on file for the duration of employment.

B.1.1 Introduction and employer/employee responsibilities.

B.1.2 Employee orientation, to include

- job description appropriate to job assignment (qualified line-clearance arborist or qualified arborist)
- introduction to immediate supervisor and crew members
- familiarization with appropriate personal protective clothing and equipment and its proper use and maintenance
- familiarization with equipment
- introduction to company policies, procedures, and safe work practices
- safe work practices as related to job assignments
- written acknowledgment by employee that he or she has participated in such training

B.1.3 Line-clearance or tree care pruning techniques appropriate to job assignments, as follows:

- B.1.3.1 Provide education and training in accordance with prevailing national standards for utility pruning. Refer to recommended resources in Annex D for further information.
- B.1.3.2 Provide education and training in accordance with prevailing local, state, or regional standards for utility pruning, as well as those specified by utility contracts.
- B.1.3.3 Provide tree knowledge for line-clearance or tree care techniques appropriate to job assignments.

- B.1.3.4 Provide education and training relative to predominant tree species within geographic area, such as identification, growth habits, structure, and wood strength.
- B.1.3.5 Provide education and training for recognition and evaluation of potentially hazardous conditions related to tree structure. Refer to recommended resources in Annex D.

B.2 GENERAL SAFETY

B.2.1 OSHA Standards

Familiarize employees with the requirements of federal and/or state OSHA standards as applicable to employee job assignments. Refer to recommended resources in Annex D.

B.2.2 American National Standards

Familiarize employees with the requirements in ANSI Z133.1 as applicable to employee job assignments. Refer to additional recommended standards in Annex D.

B.2.3 Public Safety and Traffic Control

Provide education and training in the use of public safety and traffic control devices as applicable under federal, state, or local regulations.

B.2.4 Electrical Hazards

Provide education and training in the recognition and avoidance of electrical hazards applicable to employee job assignments (line clearance or tree care).

B.2.5 Emergency Conditions

Provide education and training in the proper procedures for safely performing work in emergency conditions applicable to employee job assignments.

B.2.6 Jobsite Briefings

Provide education and training in jobsite-specific hazards associated with the job, work procedures, and practices involved. Instruct employees about special precautions, personal protective clothing, and equipment requirements as applicable to employee job assignments.

B.3 PERSONAL SAFETY

B.3.1 Personal Protective Equipment

Provide personal protective equipment as required for applicable job assignments, and instruct employees in its proper use, fit, life, and maintenance.

B.3.2 Emergency Response Procedures

Furnish employees with appropriate information and training necessary to expedite a response to a worksite emergency, such as first aid, CPR, and aerial rescue (see Annex F, Aerial Rescue Flowchart).

B.3.3 Prevention of Back and Other Injuries

Provide education and training in the techniques required to avoid back and other injuries applicable to job assignments.

B.3.4 Identification and Avoidance of Animals and Poison Plants

Provide education and training in the identification of and the need to avoid contact with poison plants and instructions for treating insect stings/bites and snake bites.

B.4 EQUIPMENT SAFETY

B.4.1 Mobile Equipment and Aerial Lifts

Provide education and training in the inspection, operation, and maintenance of all vehicles and equipment, such as aerial lifts, brush chippers, stump grinders, log loaders, tree cranes, mowing equipment, and pesticide application equipment. All equipment shall comply with applicable federal and state regulations, local ordinances, and manufacturers' operating instructions. Such training shall be appropriate to employee job assignments.

B.4.2 Aerial Equipment and Electrical Hazards

Provide education and training so that affected employees understand the required and recommended procedures for operating aerial devices in proximity to electrical hazards. Such training shall be appropriate to employee job assignments.

B.4.3 Chain Saw, Power Tool, and Hand Tool Use and Safety

Provide education and training in the safe use of chain saws, power tools, and hand tools in accordance with manufacturers' instructions. Such training shall be appropriate to employee job assignments.

B.4.4 Climbing Equipment Use and Safety

Provide education and training in the inspection, maintenance, and storage of climbing equipment such as ropes, saddles, personal lanyards, rope snaps, carabiners, and related equipment. Such training shall be appropriate to employee job assignments.

B.5 OPERATIONAL SAFETY

B.5.1 Climbing Techniques

Provide education and training in climbing techniques as appropriate to employee job assignments.

B.5.2 Rigging and Tree Removal

B.5.2.1 Provide education and training appropriate to employee job assignments, such as knots and ropes, rigging techniques, tree strength and weight characteristics, and potential electrical hazards.

B.5.2.2 Provide education and training in the identification and removal of hazard trees. Such training shall be appropriate to employee job assignments.

B.5.3 Hazard Communications

Provide education and training necessary to comply with federal and state regulations appropriate to employee job assignments.

B.5.4 Pesticide Use

Provide education and training necessary to comply with federal and state regulations appropriate to employee job assignments.

ANNEX C
(Informative)
General Safety Procedures That Apply to All Tree Work

C.1 LIFTING

Before lifting any weight, workers should

- (a) be sure there is a clear path available if the weight is to be carried from one place to another;
- (b) decide exactly how the object should be grasped to avoid sharp edges, splinters, splinters, or other factors that might cause injury;
- (c) make a preliminary lift to be sure the load can be safely handled;
- (d) place feet solidly on the walking surface;
- (e) crouch as close to the load as possible, with legs bent at an angle of about 90 degrees;
- (f) lift with the legs, not the back, keeping the weight as close to the body as possible; and
- (g) use additional workers or material-handling equipment when necessary.

C.2 CONTROL OF HAZARDOUS ENERGY

When a worker, hereafter referred to as the “authorized person,” is doing mechanical work, precautions must be taken to prevent injury caused by moving or elevated parts, or the release of stored energy, such as hydraulic pressure. Failure to do so could result in a serious, potentially maiming, or fatal injury. The authorized person performing maintenance/repair shall comply with the employer's procedures.

The specific Control of Hazardous Energy requirements established by the Occupational Safety and Health Administration (OSHA) may be obtained by consulting 29 CFR 1910.147 or by writing to the Department of Labor, OSHA, 200 Constitution Avenue NW, Washington, DC 20210.

The following are sample procedures

Sequence for Securing Equipment (Sample)

1. The authorized person shall notify the crew and/or affected employees that maintenance or repair is to be done and that such equipment must be shut down and secured.
2. The authorized person shall refer to the manufacturer's manual for proper procedures (as needed).
3. If equipment is in an operational mode, it shall be shut down by normal procedures.
4. Rotating parts, such as chipper blades, shall be stopped before maintenance or repair. Keyed ignition systems must be in working order.
5. Keys shall be removed and pocketed by the foreman or mechanic. When there is no keyed ignition system, the battery cables or spark plug wires may be disconnected.
6. The power takeoff should be disengaged before beginning service or repair tasks, such as hose replacement. All hydraulic tools should be disconnected before equipment is adjusted or serviced.
7. An employee shall never attempt to stop a hydraulic leak with his/her body.
8. Materials or parts that must be raised or disconnected and suspended shall be properly secured, such as with an appropriate sling or jackstand. Flywheels, such as chipper cutter heads, are to be blocked to prevent pinch points.
9. Before proceeding with maintenance or repair, the authorized person shall ensure that equipment is isolated and will not operate.
10. Any piece of equipment being serviced or repaired shall not be started, energized, or used by any other worker not under the direction of the authorized person.
11. When the engine must be running for tuning or adjustment, special care must be given to moving parts.

Restoring Equipment to Service (Sample)

When maintenance or repair is complete and equipment is ready to return to normal operation, the following steps shall be taken by the authorized person to restore the equipment to service:

1. To prevent accidental contact with moving or electrical components when the equipment is engaged, check for loose parts or tools that may have been left in the immediate area.
2. Ensure that all guards are in place and employees are in the clear.
3. Confirm that controls are in neutral.
4. Reconnect key, cable, or plug wires.
5. Notify affected employees that equipment is ready to return to service.

C.3 MANUAL TREE FELLING PROCEDURE

Before performing any work, conduct a site assessment and the following seven steps to determine whether a tree can be manually felled.

1. Hazards and Obstacles Identification:

Example of conditions to analyze include, but are not limited to

- (a) tree size in relationship to the landing zone;
- (b) selected direction of fall;
- (c) obstacles to avoid or clear from the felling path;
- (d) vines or interlocking limbs;
- (e) species and shape of tree;
- (f) lean of tree;
- (g) loose limbs, hangers, broken tops, chunks, or other overhead material;
- (h) wind force and direction;
- (i) decay, cavities, or weak spots throughout the tree;
- (j) location of any electrical conductors or other wires;
- (k) tree cables, bracing, lightning protection, or other tree hardware;
- (l) size and terrain characteristics or limitations of work area;
- (m) potential for flying debris from tree impact;
- (n) adequate retreat path;
- (o) evidence of bees or wildlife habitation in tree;
- (p) poisonous plants;
- (q) water hazards;
- (r) ability to control access to worksite;
- (s) authority to remove tree;
- (t) quality of wood fiber in hinge area;
- (u) root mass stability;
- (v) ice or snow load;
- (w) throwback or bounceback potential;
- (x) potential for spring poles;
- (y) lodged trees or dead snags in area;
- (z) access to tools or resources required for task;
- (aa) lightning damage;
- (bb) potential for barber chair;
- (cc) foreign objects, nails, wire fence, concrete, etc.

2. **Lean(s):** Determine side lean from the fall direction, then go 90 degrees adjacent and determine front or back lean. (Note: The side lean may influence the retreat path [escape route] as well as the back cut to be used. Heavy, forward-leaning trees may represent a risk of barber chair.)
3. **Retreat Path/Escape Route (planned retreat direction):** Select a route that is 45 degrees to the rear of the tree and, when possible, to the opposite side of the natural side lean of the tree.
4. **Notch Plan:** Select and cut a notch that is best suited to allow the tree to fall safely in the desired direction (open face, conventional, or Humboldt).
5. **Hinge Plan:** Determine the type and characteristics of the hinge. Uncut wood between the notch and back cut is recommended to have a width that is 10 percent of dbh and a hinge length that is 80 percent of the tree's diameter.
6. **Back Cut Plan:** Select and make a felling cut, such as bore cut, stepped cut(s), or level back cut(s); also use assistance, such as wedge(s), workline(s), or machinery. Before making a back cut, give an audible command, such as "stand clear," and wait for a response, such as "all clear."
7. **Retreat:** Use a retreat path (escape route) out to a safe distance. If the tree has not fallen, use workline(s) or machinery in place to start the fall of the tree. Once the tree is on the ground, wait for movement to stop and check for hanging or lodged hazards before approaching.

ANNEX D
(Informative)
Additional Resources

D.1 APPLICABLE AMERICAN NATIONAL STANDARDS

- Boom-supported Elevating Work Platforms (ANSI/SIA A92.5-2006)
- Fall Protection Systems for Construction and Demolition Operations (A10.32-2004)
- Gasoline-powered Chain Saws (B175.1-2000)
- High-visibility Safety Apparel and Head Wear Devices (107-2010)
- Industrial Head Protection (Z89.1-2009)
- Mast-climbing Work Platforms (A92.9-1993)
- Minimum Requirements for Workplace First Aid Kits and Supplies (Z308.1-2009)
- Occupational and Educational Personal Eye and Face Protection Devices (Z87.1-2010)
- Personal Fall Arrest Systems, Subsystems, and Components (Z359.1-2007)
- Portable Metal Ladders (A14.2-2007)
- Portable Reinforced Plastic Ladders (A14.5-2007)
- Portable Wood Ladders (A14.1-2007)
- Protective Headgear for Industrial Workers (Z89.1-2003)
- Supplemental Support Systems (A300-Part 3)
- Tree Care Operations—Tree, Shrub, and Other Woody Plant Maintenance (A300-Part 2)
- Vehicle-mounted Elevating and Rotating Aerial Devices (A92.2-2009)
- Workplace Walking/Working Surfaces and Their Access; Workplace, Floor, Wall, and Roof Openings: Stairs and Guardrails Systems (A1264.1-2007)

D.2 CORDAGE INSTITUTE ROPE STANDARDS

The Cordage Institute, www.ropecord.com

**D.3 APPLICABLE FEDERAL REGULATIONS (U.S. DEPARTMENT OF LABOR/
OCCUPATIONAL SAFETY AND HEALTH ADMINISTRATION, U.S. DEPARTMENT OF
LABOR/FEDERAL MOTOR CARRIER SAFETY ADMINISTRATION AND U.S.
DEPARTMENT OF TRANSPORTATION/FEDERAL HIGHWAY ADMINISTRATION)**

- Electric Power Generation, Transmission, and Distribution (29 CFR 1910.269)
- General Industry (29 CFR 1910)
- Hazard Communication (29 CFR 1910.1200)

Medical Services and First Aid (29 CFR 1910.151)

Manual on Uniform Traffic Control Devices (29 CFR, Part 655, Subpart F)

Occupational Noise Exposure (29 CFR 1910.95)

Personal Protective Equipment (29 CFR 1910.132-136)

Electrical — Safety-Related Work Practices (29 CFR 1910.331-335)

Telecommunication (29 CFR 1910.268)

Transportation (49 CFR, Subchapter B, Federal Motor Carrier Safety Regulations)

D.4 OTHER RESOURCES

D.4.1 Associations

International Society of Arboriculture; P.O. Box 3129, Champaign, IL 61826-3129

(www.isa-arbor.com)

Tree Care Industry Association; 3 Perimeter Road, Unit 1, Manchester, NH 03103

(www.treecareindustry.org)

D.4.2 Government Agencies

National Institute for Occupational Safety and Health/Fatality Assessment and Control Evaluation Program (www.cdc.gov/niosh/face)

Occupational Safety and Health Administration Safety and Health Topics for Tree Care (www.osha.gov/SLTC/treecare)


Occupational Safety and Health Administration Safety and Health Topics for Landscape and Horticultural Services (www.osha.gov/SLTC/landscaping)

ANNEX E (Informative) Weight of Green Logs

Scientific name	Common name	Weight, lb per ft ³	Weight of a 1-foot section, based on average diameter							
			10"	12"	14"	16"	18"	20"	22"	24"
<i>Abies concolor</i>	white fir	47	25	37	50	66	83	102	124	148
<i>Abies procera</i>	noble fir	29	16	23	31	41	51	63	77	91
<i>Acer rubrum</i>	red maple	50	27	39	53	70	88	109	132	157
<i>Acer saccharinum</i>	silver maple	45	25	35	48	63	79	98	119	141
<i>Acer saccharum</i>	sugar maple	56	31	44	60	78	99	122	148	176
<i>Aesculus hippocastanum</i>	horsechestnut	41	22	32	43	57	72	89	108	129
<i>Alnus rubra</i>	red alder	46	25	36	49	64	81	100	121	144
<i>Betula papyrifera</i>	paper birch	50	27	39	53	70	88	109	132	157
<i>Calocedrus decurrens</i>	incense-cedar	45	25	35	48	63	79	98	119	141
<i>Carya illinoensis</i>	pecan	61	33	48	65	85	108	133	161	192
<i>Carya ovata</i>	shagbark hickory	64	35	50	68	89	113	140	169	201
<i>Celtis occidentalis</i>	hackberry	50	27	39	53	70	88	109	132	157
<i>Diospyros virginiana</i>	persimmon	63	34	49	67	88	111	137	166	198
<i>Eucalyptus camaldulensis</i>	red gum	50	27	39	53	70	88	109	132	157
<i>Fagus</i> spp.	beech	54	29	42	58	75	95	118	142	169
<i>Fraxinus americana</i>	white ash	48	26	38	51	67	85	104	126	150
<i>Fraxinus latifolia</i>	Oregon ash	48	26	38	51	67	85	104	126	150
<i>Fraxinus pennsylvanica</i>	green ash	47	25	37	50	66	83	102	124	148
<i>Gleditsia triacanthos</i>	honeylocust	61	33	48	65	85	108	133	161	192
<i>Juglans nigra</i>	black walnut	58	32	45	62	81	102	126	153	182
<i>Larix</i> spp.	larch	51	28	40	54	71	90	111	135	160
<i>Liquidambar styraciflua</i>	sweetgum	55	30	43	58	77	97	120	145	173
<i>Liriodendron tulipifera</i>	yellow poplar, tuliptree	38	21	30	40	53	67	83	99	119
<i>Melia azedarach</i>	Chinaberry	50	27	39	53	70	88	109	132	157
<i>Nyssa sylvatica</i>	black gum	45	25	35	48	63	79	98	119	141
<i>Picea rubens</i>	red spruce	34	19	27	36	47	60	74	90	106
<i>Picea sitchensis</i>	Sitka spruce	32	17	25	34	45	56	70	84	100
<i>Pinus contorta</i>	lodgepole pine	39	21	30	41	55	69	85	103	122
<i>Pinus elliotii</i>	slash pine	58	32	45	62	81	102	126	153	182
<i>Pinus lambertiana</i>	sugar pine	52	28	41	55	72	92	113	137	163
<i>Pinus monticola</i>	western white pine	36	20	28	38	50	64	78	95	113
<i>Pinus palustris</i>	longleaf pine	55	30	43	58	77	97	120	145	173
<i>Pinus ponderosa</i>	ponderosa pine	46	25	36	49	64	81	100	121	144
<i>Pinus strobus</i>	eastern white pine	36	20	28	38	50	64	78	95	113
<i>Pinus taeda</i>	loblolly pine	53	29	41	56	74	93	116	140	166
<i>Platanus occidentalis</i>	sycamore	52	28	41	55	72	92	113	137	163
<i>Populus</i> spp.	cottonwood	49	27	38	52	68	86	107	129	154
<i>Populus tremuloides</i>	quaking aspen	43	23	34	46	60	76	94	114	135


Scientific name	Common name	Weight, lb per ft ³	Weight of a 1-foot section, based on average diameter							
			10"	12"	14"	16"	18"	20"	22"	24"
<i>Prunus serotina</i>	black cherry	45	25	35	48	63	79	98	119	141
<i>Pseudotsuga menziesii</i>	Douglas-fir	39	21	30	41	55	69	85	103	122
<i>Quercus alba</i>	white oak	62	34	48	66	86	109	135	163	194
<i>Quercus coccinea</i>	scarlet oak	64	35	50	68	89	113	140	169	201
<i>Quercus helloggii</i>	California black oak	66	36	51	70	92	116	144	174	207
<i>Quercus palustris</i>	pin oak	64	35	50	68	89	113	140	169	201
<i>Quercus robur</i>	English oak	52	28	41	55	72	92	113	137	163
<i>Quercus rubra</i>	red oak	63	34	49	67	88	111	137	166	198
<i>Quercus stellata</i>	post oak	63	34	49	67	88	111	137	166	198
<i>Quercus virginiana</i>	live oak	76	41	60	81	106	134	166	200	238
<i>Robinia pseudoacacia</i>	black locust	58	32	45	62	81	102	126	153	182
<i>Salix</i> spp.	willow	32	17	25	34	45	56	70	84	100
<i>Sequoia sempervirens</i>	coast redwood	50	27	39	53	70	88	109	132	157
<i>Taxodium distichum</i>	baldcypress	51	28	40	54	71	90	111	135	160
<i>Thuja plicata</i>	western red cedar	28	15	22	30	39	49	61	74	88
<i>Tilia americana</i>	basswood	42	23	33	45	59	74	92	111	132
<i>Tsuga canadensis</i>	eastern hemlock	49	27	38	52	68	86	107	129	154
<i>Tsuga heterophylla</i>	western hemlock	41	22	32	43	57	72	89	108	129
<i>Ulmus americana</i>	American elm	54	29	42	58	75	95	118	142	169

ANNEX F (Informative) Aerial Rescue Flowchart




**ANNEX G
(Informative)
Hand Signal Chart for Crane Operations**


From DOE-STD-1090-2004



HOIST. With forearm vertical, forefinger pointing up, move hand in small horizontal circles.




LOWER. With arm extended downward, forefinger pointing down, move hand in small horizontal circles.




USE MAIN HOIST. Tap fist on head, then use regular signals.




USE WHIPLINE. (Auxiliary Hoist)
Tap elbow with one hand, then use regular signals.




RAISE BOOM. Extend arm, fingers closed, thumb pointing upward.




LOWER BOOM. Extend arm, fingers closed, thumb pointing downward.




MOVE SLOWLY. Use one hand to give any motion signal and place other hand motionless above the hand giving the motion signal. (Hoist slowly shown as example.)




RAISE THE BOOM AND LOWER THE LOAD. With arm extended, thumb pointing up, flex fingers in and out as long as load movement is desired.




LOWER THE BOOM AND RAISE THE LOAD. With arm extended, thumb pointing down, flex fingers in and out as long as load movement is desired.




SWING. Extend arm, point with finger in direction of swing of boom.




STOP. Extend arm, palm down; move arm back and forth horizontally.




EMERGENCY STOP. Both arms extended, palms down, move arms back and forth horizontally.



TRAVEL. Extend arm forward, hand open and slightly raised; make pushing motion in direction of travel.




DOG EVERYTHING. Clasp hands in front of body.




TRAVEL (Both Tracks). Use both fists in front of body, making a circular motion about each other, indicating direction of travel, forward or backward (for land cranes only).




TRAVEL. (One Side Track). Lock the track on side indicated by raised fist. Travel opposite track indicated by circular motion of other fist, rotated vertically in front of body (for land cranes only).




EXTEND BOOM. (Telescoping Booms). Hold both fists in front of body, thumbs pointing outward.



RETRACT BOOM (Telescoping Booms). Hold both fists in front of body, thumbs pointing toward each other.



EXTEND BOOM (Telescoping Boom). One-hand signal. Hold one fist in front of chest, thumb tapping chest.



RETRACT BOOM (Telescoping Boom). One-hand signal. Hold one fist in front of chest, thumb pointing outward and heel of fist tapping chest.

ANNEX H
(Informative)
Electrical Hazard Abatement

(See Section 4.1.4 of the Standard)

H.1 ABATEMENT

When an arborist cannot safely maintain the applicable minimum approach distance from energized electric conductors, or arborist work cannot be safely completed with the line energized, the arborist must stop work on that assignment until an electrical hazard abatement plan is implemented.

An electrical hazard abatement plan may include a request for the utility to de-energize, test, and ground the electric supply lines at the worksite to make it as safe as practicable for the arborist to work closer to de-energized conductors than allowed when the conductors are electrically energized. For non-line-clearance-qualified arborists, the hazard abatement plan may require they hire a qualified line-clearance arborist or contractor to perform the work.

H.2 COMMUNICATION

When an arborist's electrical hazard abatement plan includes a request that the electrical system owner/operator de-energize, test, and ground the electrical conductors, precautions must be taken to ensure clear and thorough communications between the arborist and the onsite, qualified utility employee responsible for de-energizing and grounding the conductors. Failure to effectively communicate and maintain safe work practices could result in severe, potentially fatal injury.

H.3 GENERAL REQUIREMENTS

1. The electrical system owner/operator has the expertise, responsibility, and authority for de-energizing, testing, grounding, and re-energizing the conductors.
2. Arborist employees shall treat all conductors and equipment as energized and maintain minimum approach distances to energized conductors until they have confirmed that the utility has de-energized and tested the line and that grounding is in place to make the electric supply lines as safe as practicable for arborist work.
3. Arborists shall avoid all direct contact with the de-energized conductors, because de-energized lines should never be considered 100 percent electrically safe under all conditions.
4. Arborists shall avoid dropping brush/limbs on the de-energized electric supply lines, poles, or equipment.

The following are sample procedures

Sequence for working in proximity to de-energized and grounded electrical conductors

1. The arborist supervisor shall request that the designated utility supervisor in charge coordinate communications and actions between the arborist crew leader and the utility crew leader performing the de-energizing, testing, and grounding (i.e., times, locations, and designated contact persons at worksite where de-energizing, testing, and grounding is to apply).
2. At the worksite, a designated arborist employee in charge will be identified to the designated qualified utility employee in charge of de-energizing, testing, and grounding the conductors.
3. All arborist employees will maintain minimum approach distances until the arborist employee in charge has been notified by the qualified utility employee in charge that
 - a. the de-energizing, testing, and grounding has been completed in accordance with the electrical system owner/operator's grounding procedures, creating a safety zone for the arborist to perform work; and
 - b. the designated arborist employee in charge has visually confirmed, with the guidance of the designated qualified utility employee applying the grounds, that protective ground(s) have been installed as close as practicable to the line-clearance or arborist work to be performed to prevent hazardous differences in electrical potential.
4. It may be necessary to have the protective grounds moved by the utility if the arborist work progresses beyond the original worksite. If the grounds must be moved, Steps 1 through 3 must be repeated. The arborist crew leader must be able to visually confirm that protective ground(s) have been installed as required by the utility.

Sequence for re-energizing conductors

1. After completing the line-clearance or arborist work, the designated arborist employee in charge will verify that all arborist employees are outside of the minimum approach distances from the electric supply lines. The arborist will then inform the designated qualified utility employee in charge that the work is complete and that arborist employees are outside of the minimum approach distances. The qualified utility employee(s) may now re-energize the lines.
2. The arborist employees shall immediately treat the electrical conductors as energized and resume maintaining minimum approach distances as specified in Table 1 (for qualified line-clearance arborists) or Table 2 (for qualified arborists).

ANNEX I
(Informative)
Fall Protection Systems



WORK POSITIONING SYSTEM

Equipment designed to position the user at an elevated work site in order that he may have free use of both hands. Not intended to arrest a fall.



FALL RESTRAINT SYSTEM

Equipment designed and used to prevent the worker from reaching an area where a free fall could occur.



FALL ARREST SYSTEM

A product specifically designed to arrest a fall from an elevated position.



SUSPENSION SYSTEM

Equipment designed to suspend or lower a person to a work site. Not intended to arrest a fall.

Images courtesy of Buckingham Manufacturing Co., Inc.

INDEX

A-C

aerial devices, 10–13, 18, 39, 51, 57. *see also*
 buckets
 buckets, 10, 11, 12, 40
 and electrical cables, 12, 21
 electrical hazards, 5, 7
 air-excavation equipment, 37–38
 American National Standards, 50, 57
 apex, 39
 apparel, 2, 4
 arborists, 2, 44
 ascenders, 27, 47
 axes, 24, 40
 back cuts, 33–34, 40, 56
 backing up, 9
 backpack power units, 22
 backstays, 30
 barber chair, 33, 40, 55
 belay, 47
 blind picks, 17, 40
 body position, stable, 21
 booms, 12–13, 39, 40, 57
 brush chippers, 13–14
 brush hogs, 18, 40
 brush removal, 34–35
 buckets, 10, 11, 12, 40
 bucking, 35–36, 40
 cables and cabling, 4, 29. *see also* electrical cables
 cant dogs, 23
 cant hooks, 23, 36, 40
 carabiners, 25, 26, 30, 40
 cardiopulmonary resuscitation (CPR), 3
 chain saws, 21–22
 drop-starting, 21, 41
 in dry conditions, 28
 leg protection, 4
 for limbing, 36
 scabbards, 11
 standards, 57
 training, 51
 chippers and chipping, 13–14, 34–35
 chisels, 23

chocks, 9, 10, 46
 chopping tools, 24, 40
 climbing equipment, 25–27, 51
 climbing hitch, 27, 40
 climbing lines, 17, 23, 26–27, 28, 39, 42
 climbing spurs, 11, 27
 climbing techniques, 7, 52
 clothing, 2, 4
 come-a-long, 29
 communication. *see also* hand signals
 and electrical conductors, 65–66
 and portable power tools, 20
 radio, 17
 standards, 57
 training, 52
 when back cutting, 34
 when cutting, 28
 when rigging, 30–31
 when winching, 20
 conductors, primary, 6, 43
 connectors, quick-acting, 11, 44
 containers, approved, 4, 39
 contamination, 4, 37
 CPR (cardiopulmonary resuscitation), 3
 cranes, 16–18, 44, 62–64
 crew leaders, 16, 41
 crotches, 27, 41, 42, 47
 cutting, 11

D-F

dbh (diameter at breast height), 47
 deadman controls, 18, 41
 decontamination, personal, 37
 de-energizing, 6, 41
 dielectric, 41
 direct contact, 4, 12, 41
 direction of fall, 32, 41, 42, 43
 drop zone, 28, 29, 31, 32, 33
 drop-starting, 21, 41
 ear protection. *see* hearing protection
 electric supply, 47
 electrical cables, 12, 21

INDEX

- electrical conductors, 41
- and aerial devices, 12
- and communication, 65–66
- guarding, 47
- personal protective equipment, 3
- testing, 46
- electrical hazards, 4–7
- abatement plan, 65–66
- direct contact, 4, 12, 41
- indirect contact, 4, 42
- pesticide application, 37
- standards, 57, 58
- training, 50, 51, 53
- electrical system owner/operator, 41
- emergency procedures, 2–3, 7, 37, 50, 51
- employers/employees, 1, 41, 49
- energy absorbers, 47
- escape plans, 31, 32, 33, 34, 56
- extension cords, 21
- eye protection, 4, 9, 14, 15, 23, 37, 57
- face protection, 3, 37, 57
- fall protection, 10, 26, 47, 67
- false crotches, 27, 42, 47
- feller-bunchers, 34
- felling, manual, 32, 43, 55
- ferrules, 23
- fertilizer application, 15, 38, 39
- fire protection, 4, 28
- first aid, 3, 57, 58
- flammable liquids, 4
- footlock, 47
- footwear, 3, 7
- friction point, 47
- fuel spills, 4

- G-K**
- gaffs, 11, 27
- gloves, 7, 9, 34, 37
- gouges, 23
- ground fault, 5, 42
- grounded, 4, 42
- grub hoes, 24

- guarding, 47
- hammers, 23
- hand signals
- crane operation, 62–64
- designated signaler, 45
- and portable power tools, 20
- signal person, 16
- when back cutting, 34
- hand tools, 20–24, 51. see also saws
- handlines. see climbing lines
- hard hats, 37
- headgear, 3, 9, 37, 57
- hearing protection, 3, 9, 14, 37
- helmets, 3
- hinges, 33, 42, 56
- hitches, 27, 40, 47
- hoists and hoisting, 16, 17
- Humboldt notch, 42
- hydraulic equipment, 8, 11–12
- indirect contact, 4, 42
- infeed hoppers, 13, 35
- injuries, 51
- insects, 3, 55
- job briefings, 2, 16, 30, 35, 42, 50
- kickback, 13
- kilonewtons (kN), 42
- kilovolts (kV), 42
- knots, 27, 40, 47
- knucklebooms, 16–18

- L-O**
- ladders, 7, 24, 27, 42, 46, 57
- lanyards
- entanglement, 34
- fall-protection, 10, 43, 47
- tool, 29, 46
- work-positioning, 22, 26, 43, 46
- leans, 56
- leg protection, 4, 43
- lifting, 53
- limbing, 35–36
- limbs, 40

INDEX

- line clearance, 5–7, 12, 43, 49–50
 links, connecting, 30
 liquids, flammable, 4
 load binders, 31
 loads and loading
 radius, 17, 43
 ratings, 10
 securing, 15
 shock-, 16, 45
 suspended, 16, 18, 31, 33, 45
 working-, 29–30, 46, 48
 logs, green weight, 16, 59–60
 machetes, 40
 maintenance, 8, 54
 Material Safety Data Sheets, 37
 mattocks, 24
 mauls, 23, 43
 minimum approach distance, 5–6, 12, 43
 mobile equipment, 8–9, 51
 mowers, 34, 40
 mufflers, 28
 notches, 33, 41, 42, 43, 56
 off-road operation, 9, 18
 open-face notches, 33, 43
 outriggers, 5, 10, 11
- P-S**
- palm trees, 28
 peaveys, 23, 36
 pedestrians, 2, 34
 personal protective equipment (PPE), 3–4, 50
 air-excavation, 37
 chipping, 14, 34
 eye protection, 4, 9, 14, 15, 23, 37, 57
 face protection, 3, 37, 57
 footwear, 3, 7
 gloves, 7, 9, 34, 37
 headgear, 3, 9, 37, 57
 hearing protection, 3, 9, 14, 37
 leg protection, 4, 43
 mobile equipment, 9
 pesticide applications, 36
 spraying, 15
 standards, 57, 58
 stump cutting, 15
 winching, 18
 pesticide application, 15, 36–37, 39, 52
 phase-to-ground contact, 4, 43
 phase-to-phase contact, 4, 12, 43
 pinch points, 19, 35
 plants, poisonous, 3, 51, 55
 platforms, 7, 12–13, 39, 40, 57
 pneumatic equipment. *see* hydraulic equipment
 pole tools, 22, 28
 PPE. *see* personal protective equipment (PPE)
 pruning, 11, 49–50
 Prusik hitch, 40, 47
 Prusik loops, 25, 44
 raveling, 26
 recoil area, 19
 repair, 54
 rescue, aerial, 61
 respiratory protection, 3, 37
 rigging, 19, 28, 29–31, 52
 rollover protection, 9
 rope clips, 20
 rope snaps, 26, 45
 ropes and roping, 6, 7, 23, 25–27, 57
 saddles, 17, 25, 28, 34, 39
 safety training, 49–52
 saws, 11, 26, 31. *see also* chain saws
 scabbards, 11, 26, 28
 screw links, 26
 seatbelts, 8
 securing, 45, 54
 sheaths, 11, 28
 shock absorbers, 47
 shock-loading, 16, 45
 signal person, 16
 skid-resistant material, 8, 14, 24
 slab up, 40
 sledges, 23
 smoking, 4, 28, 38
 snags, 55

INDEX

snap hooks, 26, 45
spark arresters, 28
spars, 27, 31, 40, 45
splashguards, 15
splicing, 26
split-tail system, 25, 45
spotters, 12, 16, 45
spray equipment, 14–15
spurs, climbing, 11, 27
stabilizers. see outriggers
step potential, 45
storm work, 7
stump cutters, 15
supervision, 2, 41

T-W

taglines, 31, 33, 45
three points of contact, 27
throwlines, 23
tie in position, 7, 17, 27, 46
tongs, 23
towers, 39

towing, 9
traffic control, 2, 11, 34, 45, 50, 58
trainees, 44, personal protective equipment (PPE)
training, safety, 49–52
tree felling, manual, 32, 43, 55
tree removal, 31–34, 52
tree shear, 34
tripod/orchard ladders, 24, 46
U-bolt clips, 20
underground utilities, 15
vehicles, 8–9, 15, 18
volts, 6, 46
walking surfaces, 57
wedges, 23, 24, 36, 46
wheel chocks, 9, 10, 46
winches, 18–20, 35
wires, 4
wood chips, 15
work plans, 35
work surfaces, 57
worklines, 46
work-positioning system, 48, 67

**Recommendation to
ACCREDITED STANDARDS COMMITTEE Z133
STANDARDS FOR ARBORICULTURAL OPERATIONS
SECRETARIAT INTERNATIONAL SOCIETY OF ARBORICULTURE
P.O. Box 3129
CHAMPAIGN, IL 61826-3129**

Name: _____ Date: _____

Firm, organization, or subgroup: _____

Address: _____

Phone: _____

Fax: _____

E-mail: _____

Section/Paragraph(s): _____

Subject/Problem: _____

I recommend that: _____

Note: All recommendations must be in writing. Be concise but complete. Reference all appropriate page, section, and/or paragraph numbers unless your recommendation is for a new section. State the problem and provide a possible solution, and provide references to any resources that the committee should review in making its determination regarding your recommendation. Attach additional pages if necessary. You will receive a written response.

This section for ASC Z133 Secretariat Use Only

Received on _____ By _____

Presented to Committee on _____ Response sent on _____ By _____

Passed on _____ Rejected on _____

Subject for further study _____

Notes:



www.isa-arbor.com

ANSI Standard Z133.1 2012 - Safety Requirements - English



Z133_2012

Non-Member \$20.00
Member \$15.00